



Please cut where indicated and insert the label into the plastic pocket on the spine of the binder.



**TNV, TNN  
TRACTOR  
REPAIR**

**TN55V, TN65V, TN75V,  
TN65N, TN75N**

**Vol. 1  
86627058**




**TNV, TNN  
TRACTOR  
REPAIR**

**TN55V, TN65V, TN75V,  
TN65N, TN75N**

**Vol. 1  
86627058**







**NEW HOLLAND**

**TN55V TN65V**

**TN75V TN65N**

**TN75N**

**REPAIR  
MANUAL**

Section 00 - General

Section 10 - Engine

Section 18 - Clutch

Section 21 - Transmissions



**NEW HOLLAND**

**SERVICE**

# TN55V, TN65V, TN75V, TN65N, TN75N REPAIR MANUAL CONTENTS



**SECTION 00 - GENERAL**

**SECTION 10 - ENGINE**

**SECTION 18 - CLUTCH**

**SECTION 21 - TRANSMISSIONS**

**SECTION 23 - DRIVE LINES**

**SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION**

**SECTION 27 - REAR MECHANICAL WHEEL DRIVE**

**SECTION 31 - MECHANICAL POWER TAKE-OFF**

**SECTION 33 - BRAKING SYSTEM**

**SECTION 35 - HYDRAULIC SYSTEMS**

**SECTION 41 - STEERING**

**SECTION 44 - AXLES AND WHEELS**

**SECTION 50 - CAB AIR CONDITIONING SYSTEM**

**SECTION 55 - ELECTRICAL SYSTEM**

**SECTION 90 - PLATFORM, CAB, BODYWORK**

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TNV/TNN Tractors.

---

**GENERAL INSTRUCTIONS****IMPORTANT NOTICE**

All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

**BATTERY**

Before carrying out any kind of service operations, disconnect and isolate the battery negative lead, unless otherwise requested for specific operations (e.g.: operations that require the engine running). Once the specific operation has been completed, disconnect the lead in order to complete the operation.

**SHIMMING**

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorder values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each on shim.

**ROTATING SHAFT SEALS**

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes;
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- smear the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a flat punch; do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that the it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required;
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

**“O-RING” SEALS**

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

**SEALING COMPOUNDS**

Apply one of the following sealing compounds on the mating surfaces marked with an X: LOCTITE 518 or LOCTITE 5205.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a wire brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

**BEARINGS**

When installing bearings it is advised to:

- heat the bearings at 80 to 90 °C (176 to 194 °F) before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.

**SPRING PINS**

When fitting split socket spring pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$