

Shop Manual

WB140-2 WB150-2

BACKHOE LOADER

SERIAL NUMBERS WB140-2 - 140F10001
 WB140-2 - 30026 and up to
 WB150-2 - 150F10001

This material is proprietary to Komatsu America International Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America International Company.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

CONTENTS

	Page
10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING.....	20-1
30 DISASSEMBLY AND ASSEMBLY.....	30-1
40 MAINTENANCE STANDARD	40-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
()	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES



Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	00-1			10-30			10-76			20-23				20-69
	00-2			10-31			10-77			20-24		●	20-70	
	00-2-1			10-32			10-78			20-25				30-1
	00-2-2			10-33			10-79		●	20-26				30-2
	00-3			10-34			10-80		●	20-27				30-3
	00-4			10-35			10-81		●	20-28				30-4
	00-5			10-36			10-82		●	20-29				30-5
	00-6			10-37			10-83		●	20-30		●	30-5	
	00-7			10-38			10-84		●	20-31		●	30-6	
	00-8			10-39			10-85			20-32		●	30-7	
	00-9			10-40		●	10-86			20-33				30-8
	00-10			10-41		●	10-87			20-34				30-9
	00-11			10-42			10-88			20-35				30-10
●	00-12		●	10-43			10-89			20-36				30-11
	00-13		●	10-44			10-90			20-37		●	30-12	
	00-14			10-45			10-91			20-38				30-13
				10-46			10-92			20-39				30-14
	10-1		●	10-47			10-93		●	20-40				30-15
	10-2			10-48			10-94			20-41				30-16
●	10-3		●	10-49			10-95		●	20-42				30-17
	10-4			10-50			10-96		●	20-43				30-18
	10-5			10-51			10-97			20-44				30-19
	10-6			10-52			10-98			20-45				30-20
	10-7			10-53						20-46				30-21
●	10-8			10-54			20-1			20-47				30-22
	10-9			10-55			20-2			20-48				30-23
	10-10			10-56			20-3			20-49				30-24
	10-11			10-57			20-4			20-50				30-25
●	10-12			10-58			20-5			20-51				30-26
	10-13			10-59			20-6			20-52				30-27
	10-14			10-60			20-7			20-53				30-28
●	10-15			10-61			20-8			20-54				30-29
	10-16			10-62			20-9			20-55				30-30
	10-17			10-63			20-10			20-56				30-31
	10-18			10-64			20-11			20-57		●	30-32	
	10-19			10-65			20-12			20-58				30-33
●	10-20			10-66			20-13			20-59				30-34
	10-21		●	10-67			20-14			20-60				30-35
	10-22			10-68			20-15			20-61				30-36
	10-23			10-69			20-16			20-62		●	30-37	
	10-24			10-70			20-17			20-63				30-38
	10-25			10-71			20-18			20-64				30-39
	10-26			10-72			20-19			20-65				30-40
	10-27			10-73			20-20			20-66				30-41
	10-28			10-74			20-21			20-67				30-42
	10-29		●	10-75			20-22			20-68				30-43

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
●	30-44			30-107			30-170			30-233			30-296	
●	30-45			30-108			30-171			30-234				
●	30-46			30-109			30-172			30-235			40-1	
●	30-47			30-110			30-173			30-236			40-2	
	30-48			30-111			30-174			30-237			40-3	
	30-49			30-112			30-175			30-238			40-4	
	30-50			30-113			30-176			30-239			40-5	
	30-51			30-114			30-177			30-240			40-6	
●	30-52			30-115			30-178			30-241			40-7	
●	30-53			30-116			30-179			30-242		●	40-8	
●	30-54			30-117			30-180			30-243		●	40-9	
●	30-55			30-118			30-181			30-244		●	40-10	
	30-56			30-119			30-182			30-245		●	40-11	
	30-57			30-120			30-183			30-246		●	40-12	
●	30-58			30-121			30-184		●	30-247		●	40-13	
	30-59			30-122			30-185		●	30-248			40-14	
	30-60			30-123			30-186			30-249			40-15	
	30-61			30-124			30-187		●	30-250			40-16	
	30-62			30-125		●	30-188		●	30-251			40-17	
	30-63			30-126			30-189			30-252			40-18	
	30-64			30-127			30-190			30-253			40-19	
	30-65			30-128			30-191			30-254			40-20	
	30-66			30-129			30-192		●	30-255			40-21	
	30-67			30-130			30-193		●	30-256			40-22	
	30-68			30-131			30-194		●	30-257			40-23	
	30-69			30-132			30-195			30-258			40-24	
	30-70			30-133			30-196			30-259			40-25	
	30-71			30-134			30-197			30-260			40-26	
	30-72			30-135			30-198			30-261			40-27	
	30-73			30-136			30-199			30-262			40-28	
	30-74			30-137		●	30-200			30-263		●	40-29	
	30-75			30-138		●	30-201			30-264		●	40-30	
	30-76			30-139			30-202			30-265		●	40-31	
	30-77			30-140			30-203			30-266		●	40-32	
	30-78		●	30-141			30-204			30-267		●	40-33	
	30-79			30-142			30-205			30-268		●	40-34	
	30-80			30-143			30-206			30-269		●	40-35	
	30-81			30-144			30-207			30-270		●	40-36	
	30-82			30-145			30-208			30-271			40-37	
	30-83		●	30-146			30-209			30-272			40-38	
	30-84		●	30-147			30-210			30-273			40-39	
	30-85			30-148			30-211			30-274			40-40	
	30-86			30-149			30-212			30-275			40-41	
	30-87			30-150			30-213			30-276			40-42	
	30-88			30-151			30-214			30-277			40-43	
	30-89			30-152			30-215			30-278			40-44	
	30-90			30-153			30-216			30-279				
	30-91			30-154			30-217			30-280				
	30-92			30-155			30-218			30-281				
	30-93			30-156			30-219			30-282				
	30-94			30-157			30-220			30-283				
	30-95			30-158			30-221			30-284				
	30-96			30-159			30-222			30-285				
	30-97			30-160			30-223		●	30-286				
	30-98			30-161			30-224		●	30-287				
	30-99			30-162			30-225		●	30-288				
	30-100			30-163			30-226		●	30-289				
	30-101			30-164			30-227		●	30-290				
	30-102			30-165			30-228			30-291				
	30-103			30-166			30-229			30-292				
	30-104			30-167			30-230			30-293				
	30-105			30-168			30-231			30-294				
	30-106			30-169			30-232			30-295				



IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by Komatsu for the purpose.

To prevent injury to workers, the symbols  and  are used to mark safety precautions in this manual. The cautions accompanying these symbols should always be carefully followed. If any danger arises or may possibly arise, first consider safety, and take necessary precautions.



SAFETY

GENERAL PRECAUTIONS

Mistakes in operation extremely dangerous. Read all the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions written on the decals which are stuck on the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.
6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor.
Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding or making any repairs, park the machine on hard, level ground, and block the wheels to prevent the machine from moving.
8. Before starting work, lower ourigger, bucket or any other work equipment to the ground. If this is not possible, use blocks to prevent the work equipment from falling down. In addition, be sure to lock all the control levers and hang warning sign on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine.
Never jump on or off the machine.
If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out. Before disconnecting or removing components of the hydraulic circuit and engine cooling circuit, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are very hot when the engine is stopped, so be careful not to get burned.
Wait for the oil water to cool before carrying out any work on the cooling water circuits.

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$