Engine ManualWorkshop Manual

3TNV Series

3TNV82A · 3TNV82A-B · 3TNV84 3TNV84T · 3TNV84T-B · 3TNV88 3TNV88-B · 3TNV88-U

4TNV Series

4TNV84 · 4TNV84T · 4TNV84T-Z 4TNV88 · 4TNV88-B · 4TNV88-U 4TNV94L · 4TNV98 · 4TNV98-E 4TNV98-Z · 4TNV98T · 4TNV98T-Z 4TNV106 · 4TNV106T


Service Manual consists of the following sections.
Technical Manual
Technical Manual (Operational Principle)
Technical Manual (Troubleshooting)
Workshop Manual
Engine Manual

URL:http://www.hitachi-c-m.com

Section 1

TABLE OF CONTENTS

	Page
Introduction	1-1
Hitachi Warranties	2-1
Safety	3-1
General Service Information	4-1
Periodic Maintenance	5-1
Engine	6-1
Fuel System	7-1
Cooling System	8-1
Lubrication System	9-1
Turbocharger	10-1
Starter Motor	11-1
Alternator	12-1
ELECTRONIC CONTROL SYSTEM	13-1
Electric Wiring	14-1



This Page Intentionally Left Blank

Section 1

INTRODUCTION

This Service Manual describes the service procedures for the TNV series direct injection engines. These engines are certified by the U.S. EPA, California ARB and/or the 97/68/EC Directive for industrial use.

Please use this manual for accurate, quick and safe servicing of the engine. Since the directions in this manual are for a typical engine, some specifications and components may be different from your engine. Refer to the documentation supplied by the optional equipment manufacturer for specific service instructions.

Hitachi Construction Machinery products are continuously undergoing improvement. This Service Manual might not address possible field modifications to the equipment. Contact an authorized Hitachi industrial engine dealer or distributor for answers to any questions relating to field modifications.

This Page Intentionally Left Blank

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$