

Wheeled Loading Shovel - 411, 416

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section A - Attachments](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Hydraulic Steering](#)

[Section K - Engine](#)



Publication No.
9803/4150-17



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class
Customer Support

Section 1



General Information

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section A - Attachments](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Hydraulic Steering](#)

[Section K - Engine](#)



Publication No.
9803/4150-17



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Service, World Parts Centre, Beamhurst, Uttoxeter, Staffordshire, ST14 5PA, England. Tel +44 1889 590312 Fax +44 1889 593377

World Class
Customer Support

Notes:

Contents	Page No.
Introduction	
About this Manual	1 - 1
Machine Model and Serial Number	1 - 1
Using the Service Manual	1 - 1
Section Numbering	1 - 1
Left Side, Right Side	1 - 1
Cross References	1 - 2
Identifying Your Machine	1 - 3
Machine Identification Plate	1 - 3
Component Identification Plates	1 - 4
Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	1 - 7
Introduction	1 - 7
Bolts and Screws	1 - 7
Hydraulic Connections	1 - 11
'O' Ring Face Seal System	1 - 11
'Torque Stop' Hose System	1 - 14
Service Tools	
Numerical List	1 - 15
Tool Detail Reference	1 - 16
Section B - Body and Framework	1 - 16
Section C - Electrics	1 - 19
Section E - Hydraulics	1 - 20
Tool Detail Reference Section F - Transmission	1 - 27
Section H - Steering	1 - 29
Tool Detail Reference Section K - Engine	1 - 29
Service Consumables	
Sealing and Retaining Compounds	1 - 31
Terms and Definitions	
Colour Coding	1 - 33
Hydraulic Schematic Colour Codes	1 - 33



Section 1 - General Information

Contents	Page No.
----------	----------

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$