

Service Manual





VersaHANDLER®
Telescopic Tool Carrier (TTC)
S/N B4C311001 & Above





MAINTENANCE SAFETY



Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0807









Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.


Never



A Cleaning and maintenance are required daily.



Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause boom to drop. Do not go under boom when raised unless supported by an approved boom stop. Replace if damaged.




handler with boom up unless boom is held by an approved boom stop. Replace if damaged.

Never modify equipment or add attachments not approved by Bobcat Company.

on

telescopic


work



Have good ventilation when welding or grinding painted parts.

Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.

Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.



Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.

Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.



Lead-acid batteries produce flammable and explosive gases.

Keep arcs, sparks, flames and lighted tobacco away from batteries.

Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL. Always use genuine Bobcat replacement parts.**



CONTENTS

SAFETY AND MAINTENANCE	. 10-1
HYDRAULIC SYSTEM	. 20-1
HYDROSTATIC SYSTEM	. 30-1
DRIVE SYSTEM	. 40-1
MAINFRAME	. 50-1
ELECTRICAL SYSTEM	. 60-1
ENGINE SERVICE	. 70-1
HEATING, VENTILATION, AIR CONDITIONING (HVAC)	. 80-1
SPECIFICATIONSSF	PEC-1
ALPHABETICAL INDEX	DEX-1

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$