

WSM

WORKSHOP MANUAL **TRACTOR**

M7580, M8580, M9580

Кубота

TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractor M7580, M8580, M9580. It is divided into two parts, "Mechanism" and "Disassembling and Servicing".

■ Mechanism

Information on the construction and function are included for this section. This part should be understood before proceeding with trouble-shooting, disassembling and servicing.

■ Servicing

Under the heading "General" comes general precautions, check and maintenance and special tools. for each section, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information, illustrations and specifications contained in this manual are based on the latest production information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

May '92

© KUBOTA Corporation 1992



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and decals on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.

**DANGER**

: Immediate hazards which **WILL** result in severe personal injury or death.



WARNING : Hazards or unsafe practices which **COULD** result in severe personal injury or death.



CAUTION : Hazards or unsafe practices which **COULD** result in minor personal injury.



IMPORTANT : Indicates that equipment or property damage could result if instructions are not followed.



NOTE : Gives helpful information.

SAFETY SERVICING AND REPAIRING

(1) Before working on the machine :

- Park the machine on a firm and level ground, and set the parking brake.
- Lower the implement or mower to the ground.
- Stop the engine, and remove the key.
- Disconnect the battery's ground cable.
- Clean the work area and machine.

(2) Do not work on the machine while under the influence of alcohol, medication, or other substances or while fatigued.

(3) Do not wear a necktie, scarf, necklace, loose or bulky clothing when you work near machine tools or moving parts.

(4) Use tools appropriate to the work. Makeshift tools, parts, and procedures will not make good repairs.

(5) When servicing is performed together by two or more persons, take care to perform all work safely.

(6) Do not work under the machine that is supported solely by a jack. Always support the machine by safety stands.

- (7) If the engine must be running to do same work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.
- (8) Do not touch the rotating or hot parts while the engine is running.
- (9) Fuel is extremely flammable and explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.
- (10) To avoid sparks from an accidental short circuit, always disconnect the battery's ground cable first and connect it last.
- (11) Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, clothing and cause blindness if splashed into eyes. Keep electrolyte away from eyes, hands and clothing. If you spill electrolyte on yourself, flush with water, and get medical attention immediately.
- (12) Battery gas can explode. Keep sparks and open flame away from the top of battery, especially when charging the battery.
- (13) Never remove the radiator cap while the engine is running, or immediately after stopping. Otherwise, hot water will spout out from radiator. Wait for more than ten minutes to cool the radiator, before removing the cap.
- (14) Escaping fluid (fuel or hydraulic oil) under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or fuel lines. Tighten all connections before applying pressure.
- (15) Do not start the engine by shorting across starter terminals.
- (16) Unauthorized modifications to the machine may impair the function and / or safety and affect machine life.
- (17) Do not alter or remove any part of machine safety system.
- (18) Keep a first aid kit and fire extinguisher handy at all times.

SAFETY DECALS

- The following safety decals are installed on the machine.

If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

① Part No. 35260—3491—3 (ROPS TRACTOR)

CAUTION

TO AVOID PERSONAL INJURY:

- Read and understand the operator's manual before operation.
- Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
- Do not allow passengers on the tractor at any time.
- Before allowing other people to use the tractor, have them read the operator's manual.
- Check the tightness of all nuts and bolts regularly.
- Keep all shields in place and stay away from all moving parts.
- Lock the two brake pedals together before driving on the road.
- Slow down for turns, or rough roads, or when applying individual brakes.
- On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulation.
- Pull only from the drawbar.
- Before dismounting, lower the implement, set the parking brake, stop the engine and remove the key.

⑤ Part No. 35822—9865—2

WARNING

TO AVOID PERSONAL INJURY:

- Keep PTO shield in place at all times.
- Before using PTO, lock swinging drawbar in center position and set distance from drawbar pin hole to PTO according to the following instructions.

PTO Shaft Type	Distance
540 RPM — 6 spline 14 in. (355mm)	
1000 RPM — 21 spline 16 in. (406mm)	
- Do not operate the PTO at speeds faster than the speed recommended by the implement manufacturer.

① Part No. 35870—9836—3 (CAB TRACTOR)

CAUTION

TO AVOID PERSONAL INJURY:

- Read and understand the operator's manual before operation.
- Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
- Do not allow passengers on the tractor at any time.
- Before allowing other people to use the tractor, have them read the operator's manual.
- Check the tightness of all nuts and bolts regularly.
- Keep all shields in place and stay away from all moving parts.
- Lock the two brake pedals together before driving on the road.
- Slow down for turns, or rough roads, or when applying individual brakes.
- On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
- Pull only from the drawbar.
- Before dismounting, lower the implement, set the parking brake, stop the engine, and remove the key.
- Always use seat belt for safety when the tractor equipped with CAB or ROPS.

④ Part No. 35820—9863—3

WARNING

TO AVOID POSSIBLE INJURY OR DEATH FROM A MACHINE RUNAWAY:

- Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed.
- Start engine only from operator's seat with transmission and PTO. Never start engine while standing on the ground.

② Part No. 35260—2979—1

WARNING

TO AVOID PERSONAL INJURY:

- Attach pulled or towed loads to the drawbar only.
- Use the 3-point hitch only with equipment designed for 3-point hitch usage.

⑥ Part No. 35080—6528—2

CAUTION

Pull the engine stop knob back and hold it until the engine stops in case of emergency.

③ Part No. 35260—2978—2 (ROPS TRACTOR)

WARNING

TO AVOID PERSONAL INJURY OR DEATH FROM ROLL-OVER:

- Kubota recommends the use of a Roll-Over Protective Structures (ROPS) and seat belt in almost all applications.
- Remove the ROPS only when it substantially interferes with operation or itself presents a safety risk. (Examples include work in orchards and vineyards.)
ALWAYS REINSTALL IT BEFORE USING THE TRACTOR IN OTHER APPLICATIONS.
- Never use just the seat belt or just the ROPS. They must be used together. For further details, consult your Operator's Manual or your local dealer.

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$