

Hydraulic Breaker


B700
B850
B950
B1400



Bobcat®

Service Manual

S/N 733200101 & Above
S/N 794000101 & Above
S/N 797000101 & Above
S/N 797100101 & Above



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.



Printed in U.S.A.

MAINTENANCE SAFETY



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT



B-10731a

-  Never service attachments without instructions. See Operation & Maintenance Manual and Attachment Service Manual.
-  Cleaning and maintenance are required daily.
-  Never service or adjust attachment with the engine running unless instructed to do so in manual.
-  Always lower the attachment to the ground before lubricating or servicing.
-  Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
-  Stop, cool and clean engine of flammable materials before checking fluids.
-  Keep body, loose objects and clothing away from moving parts, electrical contacts, hot parts and exhaust.
-  Safety glasses are needed for eye protection from electrical arcs, battery acid, compressed springs, fluids under pressure and flying debris or when tools are used. Use eye protection approved for type of welding.



Bobcat®

ALPHABETICAL INDEX

ACCUMULATOR DISASSEMBLY AND ASSEMBLY	10-01, 20-01, 30-01
BREAKER BIT ASSEMBLY	10-01, 20-01, 30-01
BREAKER FRAME	10-01, 20-01, 30-01
BREAKER LUBRICATION	10-01, 20-01, 30-01
BUSHING REMOVAL AND INSTALLATION	10-01, 20-01, 30-01
ENERGY/FREQUENCY PISTON (B700)	10-01
HOSE INSTALLATION	10-01, 20-01, 30-01
HYDRAULIC FLUID FLOW EXPLANATION (B700)	10-01
NITROGEN CHAMBER	10-01, 20-01, 30-01
PARTS IDENTIFICATION	iv, vii, x
SERIAL NUMBER LOCATION	iii, vi, ix
SPECIFICATIONS AND SCHEMATICS	10-01, 20-01, 30-01

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$