


EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.

Service Manual

(450—S/N 561711001 & Above)
(453—S/N 561811001 & Above)



MELROE
INGERSOLL-RAND

6724259 (6-12)

Printed in U.S.A.

 **bobcat**
© Melroe Company 1996

MAINTENANCE SAFETY



WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.


CORRECT



B-10731a

Never service the Bobcat Skid-Steer Loader without instructions.


CORRECT



B-12365

Use the correct procedure to lift or lower operator cab.


CORRECT



B-7469

Cleaning and maintenance are required daily.


WRONG



B-11799

- Have good ventilation when welding or grinding painted parts.
- Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


WRONG



B-15231

Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


WRONG



B-15280

- Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- Never modify equipment or add attachments not approved by Bobcat Company.


WRONG



B-6590

- Stop, cool and clean engine of flammable materials before checking fluids.
- Never service or adjust loader with the engine running unless instructed to do so in the manual.
- Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- Never fill fuel tank with engine running, while smoking or when near open flame.

WRONG



B-6580

- Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- Keep rear door closed except for service. Close and latch door before operating the loader.

WRONG



B-6589

- Lead-acid batteries produce flammable and explosive gases.
- Keep arcs, sparks, flames and lit tobacco away from batteries.
- Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.



Bobcat®

ALPHABETICAL INDEX

AIR CLEANER SERVICE	1-1	OIL COOLER AND SHROUDING	7B-1
ALTERNATOR	6-1	OPERATOR CAB	1-1, 5-1
ALTERNATOR BELT ADJUSTMENT (453)	1-1	OPERATOR CAB GAS CYLINDER	5-1
ASSEMBLY OF THE ENGINE	7B-1	OPERATOR SEAT	5-1
AUXILIARY CONTROL LOCKBOLT	1-1		
AXLE HUB	4-1	PARKING BRAKE PEDAL	4-1
AXLE SEAL	4-1	PARKING BRAKE DISC	4-1
AXLE, BEARINGS AND SPROCKET	4-1	PEDAL INTERLOCK LINKAGE	2-1
		PIVOT PINS	1-1
BATTERY	6-1		
BICS™ SYSTEM CONTROLLER	8-1	RADIATOR	7B-1
BOBCAT INTERLOCK		REAR DOOR	5-1
CONTROL SYSTEM (BICS™)	8-1	REAR LIGHTS (OPTIONAL)	6-1
BOB-TACH	1-1, 5-1	REAR WINDOW	5-1
		REMOTE START SWITCH	1-1
CARBURETOR AND GOVERNOR	7A-3	REPAIRING THE ENGINE	7B-1
CHAINCASE COVERS	4-1		
CHAINCASE FLUID	4-1	SEAT BAR	5-1
CONTROL PEDALS	2-1	SEAT BAR RESTRAINT SYSTEM	1-1
CONTROL SHIELD AND		SEAT BAR SENSOR	8-1
STEERING LEVER PANELS	3-1	SEAT SENSOR	8-1
CYLINDER HEAD	7B-1	SERVICE SCHEDULE	1-1
		SPARK ARRESTOR MUFFLER	1-1
DECIMAL & MILLIMETER EQUIVALENTS	9-1	STANDARD TORQUE SPECIFICATIONS	
DRIVE BELT	3-1	FOR BOLTS	9-1
DRIVE CHAIN	4-1	STARTER	6-1
		STEERING LEVERS	3-1
ELECTRICAL SYSTEM	1-1	STEERING LINKAGE	3-1
ELECTRICAL SYSTEM INFORMATION	6-1		
ENGINE	7A-3, 7B-1	TENSION PULLEY AND SPRING	3-1
ENGINE ASSEMBLY	7A-3	TILT CYLINDER	2-1
ENGINE COOLING SYSTEM	1-1	TIRE MAINTENANCE	1-1
ENGINE DISASSEMBLY	7A-3	TOWING THE LOADER	1-1
ENGINE LUBRICATION SYSTEM	1-1	TRACTION LOCK	8-1
ENGINE SPECIFICATIONS	9-1	TRANSPORTING THE LOADER	1-1
ENGINE SPEED CONTROL	7B-1	TROUBLESHOOTING	2-1, 3-1, 6-1, 7A-3, 7B-1
FAN	7B-1		
FINAL DRIVE TRANSMISSION (CHAINCASE)	1-1	U.S. TO METRIC CONVERSION	9-1
FLYWHEEL	7A-3		
FRONT LIGHTS (OPTIONAL)	6-1		
FUEL SYSTEM	1-1, 7B-1		
FUEL TANK	5-1		
GLOSSARY OF HYDRAULIC SYMBOLS	9-1		
HYDRAULIC CONTROL VALVE	2-1		
HYDRAULIC CYLINDERS	2-1		
HYDRAULIC FILTER BLOCK	3-1		
HYDRAULIC/HYDROSTATIC			
FLUID SPECIFICATIONS	9-1		
HYDRAULIC/HYDROSTATIC SYSTEM	1-1		
HYDRAULIC PUMP	2-1		
HYDRAULIC RESERVOIR	2-1		
HYDRAULIC SYSTEM INFORMATION	2-1		
HYDROSTATIC MOTOR	3-1		
HYDROSTATIC PUMP	3-1		
HYDROSTATIC SYSTEM INFORMATION	3-1		
IGNITION SYSTEM	7A-3		
INSTRUMENT PANEL	6-1		
LIFT ARM BY-PASS BLOCK	2-1		
LIFT ARM SUPPORT DEVICE	1-1		
LIFT ARMS	5-1		
LIFT CYLINDER(S)	2-1		
LIFT AND TILT LOCK BY-PASS VALVE	8-1		
LIFTING AND BLOCKING THE LOADER	1-1		
LIFTING THE LOADER	1-1		
LOADER SPECIFICATIONS	9-1		
LUBRICATING THE LOADER	1-1		

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$