Equipment Components Parts Catalog 機器インナーパーツカタログ

ΔΧ 38u-6A **Hydraulic Excavator** 油圧ショベル

@Hitachi Construction Machinery Co., Ltd. URL:http://www.hitachi-c-m.com

MEMORANDUM

メ モ 欄

Correctly fill in the following columns. Use these information when ordering the service parts and servicing the machine.

下表を部品注文,機械管理等にご利用ください。

Product Identification Number	
製 品 識 別 番 号	
Engine Type	VANIMAD (>) . 2TNIV/00
エ ン ジ ン 型 式	YANMAR (ヤンマー): 3TNV88
Engine Mfg. Number	
エンジン製番	

This parts catalog shows the precision parts of AX38u-6A Series Hydraulic Excavator.このパーツカタログは、AX38u-6A シリーズ油圧ショベルに使用している油圧機器等の精密部品を掲載してあります。

まえがき

- ◎ 当社では、製品の改良にたえず努力をはらっておりますので、パーツカタログに記載されていない変更が生じている場合があります。不明の点がございましたら、最寄りの支店または営業所にご相談ください。
- 1. 部品のご注文について 部品をご注文の際には、製品型式名,製品識別番号, 部品番号,部品名,数量を、最寄りの支店または営業 所へご連絡ください。
- 2. パーツカタログの見方

部 品 名:部品の名称です。組立品を構成する部 品は、部品名の前に「*」印を付けて 記載しています。

数 量: 「各機器の1セット分の個数」を示します。組立品を構成する部品は、 「1組分の個数」を示します。

記号の説明:サービスコード欄および互換性に記載 している各記号の意味は、次の通りで す。

W: 現地加工作業が必要ですので、当社にご用命 ください。

D: 単品では交換できませんので、組部品で交換 してください。

K: サービスパーツキットに含まれています。

R: 調整用シムなどのように使用する数量が号機 毎に異る事を示します。

S: 修理,サービス用として供給する部品です。

OS: オーバーサイズ部品を示します。

US: アンダーサイズ部品を示します。 (OS, US はスタンダードサイズ部品の 次の行に、続けて記載しています。)

#: このパーツカタログから、その部品の含まれている装置のリストのページに新しく記載した部品であることを示します。

Y: 無条件で互換性があります。

I: その部品の代りに使用できる部品の部品番号と数量を、代替部品欄に示します。ただし、 代替部品欄に示す部品の代りに、その部品を 使用することはできません。

T: 組み合わせで互換性があります。

P: その部品は使用禁止になっています。代替部 品欄に示す部品を使用してください。

適 用 号 機: 号機は、製品識別番号の下6桁の数字 をいいます。

D: 変更切換時期を年月で表わします。 (例; D03/09-・・2003年9月 以降この部品を使用。)

H: 機器の製造番号を表わします。

F: フロントアタッチメントの製造番号を表わします。

代 替 部 品: 互換性欄の記号に対応して、代替に使 用する部品の部品番号と数量を示しま

> 《注記》: 部品をご注文の際、互換性欄に Y, I, Pと記載されている場合、自動的 に代替部品欄に示されている部品が供 給されることがあります。

FOREWORD

According to Hitachi's continuous effort to improve the product quality, descriptions in the Parts Catalog may be slightly different from your machine. If any questionable points are found, feel free to contact your nearest Hitachi dealer.

1. HOW TO ORDER PARTS

When ordering parts, please specify the following items.

- (1) Model/type
- (2) Product Identification Number
- (3) Part No.
- (4) Part Name
- (5) Q'ty
- (6) Purchaser's Name and Address

2. HOW TO USE THIS PARTS CATALOG

PART NAME: When the part is used as an inner part

of an assembly part, the mark "*" is

shown in front of the part name.

Q'TY: Q'ty shows the quantity used for a

particular single hydraulic unit, however quantity of components shows the quantity for one assembly

part.

SYMBOLS USED IN THIS BOOK:

The symbols shown in the service code and interchangeability columns are used to indicate the following information.

- W: Requires additional processing at the job site. Ask your nearest Hitachi dealer.
- D: Impossible to replace as a single part. Replace the part in an assembly unit.
- K: Contained in the service part kit.
- R: Indicate that the quantity of the part like shims differs depending on the machine serial No.
- S: To be supplied as repair or service parts.
- OS: Over-sized parts
- US: Undersized parts
 (Part with mark "OS, or US" is described in the next column under the standard size part column.)
- #: Indicates newly added parts to the equipment or component.
- Y: Interchangeable part without any constraint.

- I: Used to indicate the part No. and quantity of the part to be used for the part concerned in the replacement part column. However, the part concerned is not used for the part shown with mark I.
- T: Becomes interchangeable when combined.
- P: Indicate the part prohibited to use. Use the part shown in the replacement part column.

SERIAL No.: The serial number corresponds to the last six-digit figure of the PIN (Product Identification Number) on the name-plate.

- D: Represents the date of modification.
 (Example: D03/09: New modification part has been applied to the products manufactured in and after Sept 2003.)
- H: Indicates the component manufacturing
- F: Indicates the front attachment manufacturing No

REPLACEABLE PART:

Indicates the part No. and quantity per machine of the replacement part.

NOTE: When the part with mark Y, I, or P shown in the interchangeability column is ordered, the part shown in the replacement part column may be automatically supplied instead of the ordered part.

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$