WENBM00310

Shop Manual

HYDRAULIC EXCAVATOR

PC138US-11E0 SERIAL NUMBERS 59832 and up
F60001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD 00-1
FOREWORD, SAFETY, BASIC INFORMATION 00-20
HOW TO READ THE SHOP MANUAL 00-20
SAFETY NOTICE FOR OPERATION 00-22
PRECAUTIONS TO PREVENT FIRE 00-30
ACTIONS IF FIRE OCCURS 00-32
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS 00-33
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS 00-34
PRECAUTIONS FOR DEF 00-35
STORE AdBlue/DEF 00-36
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT 00-37
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS 00-40
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT 00-47
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT 00-49
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT 00-50
PRACTICAL USE OF KOMTRAX 00-51
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER 00-52
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS 00-56
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR 00-60
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR 00-61
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL 00-63
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH 00-64
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE 00-66
HOW TO READ ELECTRICAL WIRE CODE 00-67
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD 00-71
STANDARD TIGHTENING TORQUE TABLE 00-74
CONVERSION TABLE 00-81
ABBREVIATION LIST 00-86
01 SPECIFICATIONS 01-1
CONTENTS 01-2
SPECIFICATIONS 01-3
SPECIFICATION DRAWING 01-3
WORKING RANGE DRAWINGS 01-5
SPECIFICATIONS 01-6
WEIGHT TABLE 01-10
FUEL, COOLANT, LUBRICANT 01-12
10 STRUCTURE AND FUNCTION 10-1
CONTENTS 10-2
UREA SCR SYSTEM 10-5
LAYOUT DRAWING OF UREA SCR SYSTEM 10-5
UREA SCR SYSTEM DIAGRAM 10-7
FUNCTION OF UREA SCR SYSTEM 10-8
COMPONENT PARTS OF UREA SCR SYSTEM 10-19
BOOT-UP SYSTEM 10-28
LAYOUT DRAWING OF BOOT-UP SYSTEM 10-28
SYSTEM OPERATING LAMP SYSTEM 10-29
BATTERY DISCONNECT SWITCH 10-30
ENGINE SYSTEM 10-31
LAYOUT DRAWING OF ENGINE SYSTEM 10-31
ENGINE CONTROL SYSTEM 10-33
AUTO-DECELERATION SYSTEM 10-36
ENGINE AUTOMATIC WARM-UP SYSTEM 10-38
OVERHEAT PREVENTION SYSTEM 10-40
TURBOCHARGER PROTECTION SYSTEM 10-42
AUTOMATIC IDLE STOP SYSTEM 10-43

COMPONENT PARTS OF ENGINE SYSTEM 10-46
COOLING SYSTEM 10-68
LAYOUT DRAWING OF COOLING SYSTEM 10-68
FAN SPEED CONTROL SYSTEM OF FAN CLUTCH 10-70
ENGINE OUTPUT CONTROL SYSTEM OF FAN CLUTCH 10-72
COMPONENT PARTS OF COOLING SYSTEM 10-74
CONTROL SYSTEM 10-75
LAYOUT DRAWING OF CONTROL SYSTEM 10-75
MACHINE MONITOR SYSTEM 10-77
KomVision SYSTEM 10-79
KOMTRAX SYSTEM 10-83
COMPONENT PARTS OF CONTROL SYSTEM 10-84
HYDRAULIC SYSTEM 10-125
LAYOUT DRAWING OF HYDRAULIC SYSTEM 10-125
CLSS 10-127
ENGINE AND PUMP COMBINED CONTROL SYSTEM 10-130
COMPONENT PARTS OF HYDRAULIC SYSTEM 10-135
WORK EQUIPMENT SYSTEM 10-224
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM 10-224
STRUCTURE OF VALVE CONTROL 10-227
PPC LOCK SYSTEM 10-228
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM 10-229
OIL FLOW ADJUSTER SYSTEM FOR ATTACHMENT 10-231
TOOL CONTROL SYSTEM 10-233
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM 10-235
SWING SYSTEM 10-262
LAYOUT DRAWING OF SWING SYSTEM 10-262
SWING CONTROL SYSTEM DIAGRAM 10-264
COMPONENT PARTS OF SWING SYSTEM 10-267
TRAVEL SYSTEM 10-280
LAYOUT DRAWING OF TRAVEL SYSTEM 10-280
TRAVEL CONTROL SYSTEM DIAGRAM 10-282
COMPONENT PARTS OF TRAVEL SYSTEM 10-286
UNDERCARRIAGE AND FRAME 10-302
LAYOUT DRAWING OF UNDERCARRIAGE 10-302
IDLER CUSHION 10-303
WORK EQUIPMENT 10-304
STRUCTURE OF WORK EQUIPMENT 10-304
FUNCTION OF WORK EQUIPMENT 10-305
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM 10-306
BUCKET CLEARANCE ADJUSTMENT SHIM 10-307
CAB AND ITS ATTACHMENTS 10-308
ROPS CAB 10-308
CAB MOUNT 10-309
TAKE WIRING HARNESS OUT OF CAB 10-311
20 STANDARD VALUE TABLE 20-1
CONTENTS 20-2
STANDARD VALUE TABLE FOR ENGINE 20-3
STANDARD VALUE TABLE FOR ENGINE:PC138US-11E0 20-3
STANDARD VALUE TABLE FOR MACHINE 20-7
STANDARD VALUE TABLE FOR MACHINE:PC138US-11E0 20-7
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE 20-21
30 TESTING AND ADJUSTING 30-1
CONTENTS 30-2
RELATED INFORMATION ON TESTING AND ADJUSTING 30-6
TOOLS FOR TESTING AND ADJUSTING 30-6
SKETCH OF TOOLS FOR TESTING AND ADJUSTING 30-13
ENGINE AND COOLING SYSTEM 30-15

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2$