

# SERVICE MANUAL

## **F5** **Tier 4B (final) and Stage IV** **Engine**

*See the following page for engine model numbers*



## SERVICE MANUAL

F5BFL413A\*B001 , F5BFL413A\*B003 , F5BFL413A\*B007 , F5BFL413A\*B009 ,  
F5BFL413D\*B002 , F5BFL413D\*B003 , F5BFL413F\*B002 , F5BFL413F\*B003 ,  
F5DFL463A\*F007 , F5DFL463A\*F013 , F5DFL463A\*F014 , F5DFL463A\*F019 ,  
F5DFL463A\*F020 , F5DFL463B\*F003 , F5DFL463B\*F004 , F5DFL463B\*F006 ,  
F5DFL463C\*F001 , F5DFL463C\*F002 , F5DFL463C\*F004 , F5GFL413A\*B003 ,  
F5GFL413A\*B004 , F5GFL413A\*B006 , F5GFL413A\*B007 , F5GFL413A\*B012 ,  
F5GFL413A\*B013 , F5HFL463A\*F001 , F5HFL463A\*F002 , F5HFL463A\*F003 ,  
F5HFL463A\*F004 , F5HFL463A\*F005 , F5HFL463A\*F006 , F5HFL463A\*F007 ,  
F5HFL463A\*F008 , F5HFL463B\*F001 , F5HFL463B\*F002 , F5HFL463C\*F001 ,  
F5HFL463C\*F002 , F5HFL463D\*F001 , F5HFL463D\*F004 , F5HFL463D\*F005 ,  
F5HFL463D\*F006

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.101] Cylinder heads .....	10.2
[10.102] Pan and covers .....	10.3
[10.103] Crankshaft and flywheel.....	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.106] Valve drive and gears .....	10.6
[10.114] Pump drives .....	10.7
[10.206] Fuel filters .....	10.8
[10.218] Fuel injection system.....	10.9
[10.250] Turbocharger and lines.....	10.10
[10.254] Intake and exhaust manifolds and muffler .....	10.11
[10.304] Engine lubrication system.....	10.12
[10.400] Engine cooling system .....	10.13
[10.408] Oil cooler and lines.....	10.14
[10.414] Fan and drive .....	10.15
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.16
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment .....	10.17
Electrical systems .....	55
[55.010] Fuel injection system.....	55.1
[55.012] Engine cooling system .....	55.2
[55.013] Engine oil system .....	55.3
[55.014] Engine intake and exhaust system.....	55.4
[55.015] Engine control system.....	55.5
[55.201] Engine starting system.....	55.6

[55.202] Cold start aid .....	55.7
[55.301] Alternator.....	55.8
[55.988] Selective Catalytic Reduction (SCR) electrical system .....	55.9
[55.989] Exhaust Gas Recirculation (EGR) electrical system .....	55.10



It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$