



## SERVICE MANUAL



**MAXXUM 100 , MAXXUM 110 Multicontroller , MAXXUM 110 , MAXXUM 115 Multicontroller , MAXXUM 115 , MAXXUM 120 Multicontroller , MAXXUM 120 , MAXXUM 125 Multicontroller , MAXXUM 125 , MAXXUM 130 Multicontroller , MAXXUM 130 , MAXXUM 140 Multicontroller , MAXXUM 140**

# Contents

---

## INTRODUCTION

## HYDRAULIC - PNEUMATIC - ELECTRICAL - ELECTRONIC SYSTEMS A

PRIMARY HYDRAULIC POWER SYSTEM.....	A.10.A
PRIMARY HYDRAULIC POWER SYSTEM Closed center mechanical remote valve ....	A.10.B
PRIMARY HYDRAULIC POWER SYSTEM Electro-hydraulic remote valve.....	A.10.C
PRIMARY HYDRAULIC POWER SYSTEM Open center mechanical remote valve.....	A.10.D
SECONDARY HYDRAULIC POWER SYSTEM.....	A.12.A
HYDRAULIC COMMAND SYSTEM.....	A.14.A
ELECTRICAL POWER SYSTEM .....	A.30.A
ELECTRICAL POWER SYSTEM .....	A.30.A
ELECTRONIC SYSTEM .....	A.50.A
FAULT CODES.....	A.50.A

## ENGINE AND PTO IN ..... B

ENGINE .....	B.10.A
FUEL AND INJECTION SYSTEM.....	B.20.A
AIR INTAKE SYSTEM.....	B.30.A
EXHAUST SYSTEM.....	B.40.A
ENGINE COOLANT SYSTEM .....	B.50.A
STARTING SYSTEM .....	B.80.A

## TRANSMISSION, DRIVE AND PTO OUT ..... C

POWER COUPLING Clutch.....	C.10.C
TRANSMISSION Mechanical .....	C.20.B
TRANSMISSION Power Shuttle.....	C.20.C
TRANSMISSION Semi-Powershift .....	C.20.D
ADDITIONAL REDUCERS Creeper.....	C.30.C
ADDITIONAL REDUCERS Overdrive.....	C.30.D
REAR PTO Hydraulic.....	C.40.C
FRONT PTO Hydraulic .....	C.42.C

## AXLES, BRAKES AND STEERING..... D

FRONT AXLE .....	D.10.A
REAR AXLE .....	D.12.A
2WD-4WD SYSTEM Hydraulic .....	D.14.C
STEERING Hydraulic .....	D.20.C
SERVICE BRAKE Hydraulic .....	D.30.C
PARKING BRAKE Mechanical .....	D.32.B
BRAKE CONNECTION Hydraulic .....	D.34.C
SUSPENSION Hydraulic .....	D.40.C
WHEELS AND TRACKS Wheels .....	D.50.C
<b>FRAME AND CAB .....</b>	<b>E</b>
FRAME Primary frame .....	E.10.B
SHIELD .....	E.20.A
USER CONTROLS AND SEAT .....	E.32.A
USER PLATFORM .....	E.34.A
ENVIRONMENT CONTROL Heating, ventilation and air-conditioning .....	E.40.D
<b>HITCH AND WORKING TOOL .....</b>	<b>H</b>
HITCH Front hitch .....	H.10.B
HITCH Rear hitch .....	H.10.C
HITCH Electronic draft control .....	H.10.D





## INTRODUCTION

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$