SERVICE MANUAL

SERVICE MANUAL

E385C

Hino Diesel Engine J08E-TM Supplement to Service Manual 47374920A

E385C

Hino Diesel Engine J08E-TM

Supplement to

Service Manual

47374920A

Print No. 47391168A

Print No. 47391168A





SERVICE MANUAL

E385C

Hino Diesel Engine J08E-TM

Supplement to Service Manual 47374920A





Read this manual before operating the machine

Most accidents occurring during work are due to non-observance of simple safety norms and elementary precautions.


Many accidents can be avoided if the causes are known and opportune cautions taken beforehand.

There is no device or protection, no matter how advanced, that may prove so effective at avoiding accidents as a careful and attentive behaviour.

Strada di Settimo, 323 - S. MAURO T.SE (TO) ITALY

ENGINE

(HINO DIESEL ENGINE J08E-TM) CONTENTS



Group 1	General	W5-1
Group 2	Standard Value	W5-2
Group 3	Parts to be prepared	W5-3
Group 4	Engine assembly/disassembly	W5-4
Group 5	Fuel System	W5-5
Group 6	Emission Control	
Group 7	Electrical	W5-7
Group 8	Intake	W5-8
Group 9	Engine Mechanical	W5-9
Group 10	Exhaust	W5-10
Group 11	Cooling	W5-11
Group 12	Lubrication	
Group 13	Starting and Charging	W5-13
Group 14	Turbocharger	
Group 15	Failure Diagnosis for each Engine Status	
Group 16	Engine Diagnosis Code	

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$