

# SERVICE MANUAL

## LM5020 / LM5030 / Tier 3 Telescopic Handler

Part number 47787942  
English  
October 2014





# **SERVICE MANUAL**

**LM5020**  
**LM5030**

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
Four-Wheel Drive (4WD) system .....	23
[23.314] Drive shaft.....	23.1
Front axle system .....	25
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3
Rear axle system.....	27
[27.550] Non-powered rear axle.....	27.1
Hydrostatic drive.....	29
[29.202] Hydrostatic transmission .....	29.1
Brakes and controls .....	33
[33.120] Mechanical service brakes .....	33.1
[33.202] Hydraulic service brakes .....	33.2
[33.110] Parking brake or parking lock .....	33.3
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.106] Variable displacement pump .....	35.2
[35.353] Hydraulic travel system .....	35.3
[35.359] Main control valve.....	35.4
[35.740] Telescopic arm hydraulic system.....	35.5
Steering.....	41
[41.216] Cylinders .....	41.1

[41.101] Steering control .....	41.2
<b>Cab climate control .....</b>	<b>50</b>
[50.200] Air conditioning.....	50.1
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.512] Cab controls.....	55.3
[55.524] Cab controls (Lift arm, Boom, Dipper, Bucket).....	55.4
[55.408] Warning indicators, alarms, and instruments .....	55.5



It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$