

SERVICE MANUAL

T6.125 / T6.145 / T6.155 / T6.165 / T6.175 / T6.180
T6.145 AutoCommand™ / T6.155 AutoCommand™
T6.165 AutoCommand™ / T6.175 AutoCommand™
Tier 4B (final)
Tractor

Part number 47938738
1st edition English
October 2015





SERVICE MANUAL

**T6.125 , T6.145 AutoCommand™ , T6.145 , T6.155 AutoCommand™ , T6.155 ,
T6.165 AutoCommand™ , T6.165 , T6.175 AutoCommand™ , T6.175 , T6.180**

Link Product / Engine

| Product | Market Product | Engine |
|---------------------|-----------------------|----------------|
| T6.145 AutoCommand™ | North America | F4DFE4134*B005 |
| T6.155 AutoCommand™ | North America | F4DFE4133*B007 |
| T6.165 AutoCommand™ | North America | F4DFE4132*B005 |
| T6.175 AutoCommand™ | North America | F4DFE4131*B007 |
| T6.125 | North America | F4DFE414D*B001 |
| T6.145 | North America | F4DFE4134*B006 |
| T6.155 | North America | F4DFE4133*B008 |
| T6.165 | North America | F4DFE4132*B006 |
| T6.175 | North America | F4DFE4131*B008 |
| T6.180 | North America | F4DFE6132*B007 |

Contents

INTRODUCTION

| | |
|--|-----------|
| Engine | 10 |
| [10.001] Engine and crankcase | 10.1 |
| [10.216] Fuel tanks | 10.2 |
| [10.202] Air cleaners and lines | 10.3 |
| [10.254] Intake and exhaust manifolds and muffler | 10.4 |
| [10.500] Selective Catalytic Reduction (SCR) exhaust treatment..... | 10.5 |
| [10.400] Engine cooling system | 10.6 |
| [10.414] Fan and drive | 10.7 |
| [10.310] Aftercooler..... | 10.8 |
| [10.304] Engine lubrication system..... | 10.9 |
| Clutch | 18 |
| [18.112] Slip clutch or flywheel damper | 18.1 |
| Transmission | 21 |
| [21.111] Semi-Powershift transmission | 21.1 |
| [21.133] Semi-Powershift transmission external controls | 21.2 |
| [21.103] Semi-Powershift transmission lubrication system..... | 21.3 |
| [21.152] Semi-Powershift transmission internal components | 21.4 |
| [21.504] Continuously Variable Transmission (CVT) | 21.5 |
| [21.505] Continuously Variable Transmission (CVT) external controls..... | 21.6 |
| [21.506] Continuously Variable Transmission (CVT) lubrication system | 21.7 |
| [21.507] Continuously Variable Transmission (CVT) internal components..... | 21.8 |
| [21.160] Creeper | 21.9 |
| [21.166] Overdrive..... | 21.10 |
| Four-Wheel Drive (4WD) system | 23 |
| [23.202] Electro-hydraulic control | 23.1 |

| | |
|---|-----------|
| [23.314] Drive shaft..... | 23.2 |
| Front axle system | 25 |
| [25.100] Powered front axle | 25.1 |
| [25.102] Front bevel gear set and differential | 25.2 |
| [25.108] Final drive hub, steering knuckles, and shafts | 25.3 |
| [25.122] Axle suspension control..... | 25.4 |
| Rear axle system..... | 27 |
| [27.100] Powered rear axle..... | 27.1 |
| [27.106] Rear bevel gear set and differential..... | 27.2 |
| [27.120] Planetary and final drives | 27.3 |
| Power Take-Off (PTO)..... | 31 |
| [31.104] Rear electro-hydraulic control..... | 31.1 |
| [31.114] Two-speed rear Power Take-Off (PTO) | 31.2 |
| [31.142] Front Power Take-Off (PTO) control | 31.3 |
| [31.146] Front Power Take-Off (PTO) | 31.4 |
| Brakes and controls | 33 |
| [33.202] Hydraulic service brakes | 33.1 |
| [33.110] Parking brake or parking lock | 33.2 |
| [33.220] Trailer brake hydraulic control..... | 33.3 |
| [33.224] Trailer brake pneumatic control | 33.4 |
| [33.204] Front axle brake | 33.5 |
| Hydraulic systems..... | 35 |
| [35.000] Hydraulic systems..... | 35.1 |
| [35.300] Reservoir, cooler, and filters..... | 35.2 |
| [35.104] Fixed displacement pump..... | 35.3 |
| [35.106] Variable displacement pump | 35.4 |
| [35.105] Charge pump..... | 35.5 |
| [35.322] Regulated/Low pressure system | 35.6 |

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$