

585G/586G/588G Forklift Service Manual 7-14851

Table of Contents

Description	Section No.	Form No.
General		Tab 1
Section Index - General		7-15500
Standard Torque Specifications	1001	8-71601
Fluids and Lubricants	1002	7-15160
Loctite Product Chart		8-98900
Engines		Tab 2
Section Index - Engines		7-15510
Engine Removal and Installation	2000	7-15520
Stall Test	2001	7-15170
Electrical		Tab 4
Section Index - Electrical		7-15530
Removal and Installation of Electrical Components	4000	7-15540
Electrical Specifications and Troubleshooting	4001	7-14860
Batteries	4003	7-49440
Starter Motor - Denso	4003	7-11450
Instrument Cluster	4005	7-49560
Alternator	4007	7-49250
Steering		Tab 5
Section Index - Steering		7-15550
Removal and Installation of Steering Components	5000	7-15560
Steering Specifications, Pressure Checks and Troubleshooting	5001	7-15180
Steering Control Valve	5002	7-15570
Steering Cylinders	5003	7-11930
Steering Axle - Two Wheel Drive	5005	7-15310
Steering Axle - Four Wheel Drive	5006	7-15320

Reprinted

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Bur 7-15491

© 2000 Case Corporation
Printed in U.S.A.
June, 1999 (Revised March, 2000)

585G/586G/588G Forklift Service Manual 7-14851

Table of Contents

Description	Section No.	Form No.
Power Train		
	Tab 6	
Section Index - Power Train		7-15581
Removal and Installation of Power Train Components	6000	7-15590
Transmission Specifications, Pressure Checks and Troubleshooting - Forklift Early Production	6002	7-15710
Transmission Specifications, Pressure Checks and Troubleshooting - Forklift Late Production	6002	7-15800
Wheels and Tires	6003	7-15400
Drive Axle and Planetaries	6004	7-15601
Standard (Carraro) Transmission	6007	7-10431
Brakes		
	Tab 7	
Section Index - Brakes		7-15610
Removal and Installation of Brake Components	7000	7-15620
Master Cylinder	7003	7-49490
Hydraulics		
	Tab 8	
Section Index - Hydraulics		7-15630
Removal and Installation of Hydraulic Components	8001	7-15640
Hydraulic Specifications, Troubleshooting, and Pressure Checks	8002	7-15190
Cleaning the Hydraulic System	8003	7-49640
Hydraulic Pump	8004	7-16050
Control Valve	8005	7-15660
Flow Control Priority Valve	8006	7-15670
Cylinders	8010	7-15300
Mounted Equipment		
	Tab 9	
Section Index - Mounted Equipment		7-15680
Pedals and Levers	9001	7-15200
ROPS Canopy	9007	7-15690
Seat and Seat Belts	9009	7-15650
Forklift Mast	9010	7-15700
Hydraulic and Electrical Schematic Foldout	In Rear Pocket	7-15140

NOTE: Case Corporation reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

SECTION INDEX - GENERAL

Section Title

Section Number

Standard Torque Specifications.....	1001
Fluid and Lubricants.....	1002
Loctite Product Chart	

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Section 1001

STANDARD TORQUE SPECIFICATIONS

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
3350 South Service Road
Burlington, ON L7N 3M6 CANADA

Rac 8-71601

© 1994 Case Corporation
Printed in U.S.A.
Issued November, 1991

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$