

AXIAL-FLOW® 7230
AXIAL-FLOW® 8230
AXIAL-FLOW® 9230
Rotary Combine

SERVICE MANUAL

Part number 48040837

English

August 2017

© 2017 CNH Industrial Latin America LTDA. All Rights Reserved.





SERVICE MANUAL

**AXIAL-FLOW® 7230 Machine Standard Tier III produced in Brazil.,
AXIAL-FLOW® 7230 Machine with Power Guide Axle Tier III produced in
Brazil, AXIAL-FLOW® 8230 Machine Standard Tier III produced in Brazil.,
AXIAL-FLOW® 8230 Machine with Power Guide Axle Tier III produced in
Brazil. , AXIAL-FLOW® 9230 Machine Standard Tier III produced in Brazil.,
AXIAL-FLOW® 9230 Machine with Power Guide Axle Tier III produced in
Brazil.**

Link Product / Engine

Product	Market Product	Engine
AXIAL-FLOW® 7230 Máquina com Power Guide Axle Tier III produzida no Brasil	Latin America	F3AE9684A*E001
AXIAL-FLOW® 7230 Máquina com Power Guide Axle Tier III produzida no Brasil	Latin America	F3AE9684A*E001
AXIAL-FLOW® 8230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684A*E001
AXIAL-FLOW® 8230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684A*E001
AXIAL-FLOW® 9230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684B*E002
AXIAL-FLOW® 9230 Máquina com Power Guide Axle Tier III produzida no Brasil.	Latin America	F3BE3684B*E002

Contents

INTRODUCTION

Engine	10
[10.202] Air cleaners and lines	10.1
[10.216] Fuel tanks	10.2
[10.218] Fuel injection system.....	10.3
[10.310] Aftercooler.....	10.4
[10.400] Engine cooling system	10.5
[10.414] Fan and drive	10.6
[10.418] Rotary screen	10.7
[10.450] Engine air compressor	10.8
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.9
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Transmission	21
[21.100] Mechanical transmission hydraulic components	21.1
[21.114] Mechanical transmission	21.2
[21.130] Mechanical transmission external controls.....	21.3
[21.145] Gearbox internal components.....	21.4
[21.182] Differential	21.5
Front axle system	25
[25.100] Powered front axle	25.1
[25.108] Final drive hub, steering knuckles, and shafts	25.2
[25.310] Final drives	25.3
Rear axle system	27
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts	27.2

[27.550] Non-powered rear axle	27.3
Hydrostatic drive	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.134] Two-speed assembly	29.2
[29.202] Hydrostatic transmission	29.3
[29.218] Pump and motor components	29.4
[29.300] Rear hydrostatic transmission	29.5
Power Take-Off (PTO)	31
[31.146] Front Power Take-Off (PTO)	31.1
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems	35
[35.000] Hydraulic systems	35.1
[35.102] Pump control valves	35.2
[35.106] Variable displacement pump	35.3
[35.220] Auxiliary hydraulic pump	35.4
[35.300] Reservoir, cooler, and filters	35.5
[35.350] Safety and main relief valves	35.6
[35.359] Main control valve	35.7
[35.410] Header or attachment height system	35.8
[35.415] Header or attachment tilting system	35.9
[35.440] Grain tank unload system	35.10
[35.518] Reel control system	35.11
[35.536] Crop processor system	35.12
[35.796] Chaff spreader control	35.13
Steering	41
[41.101] Steering control	41.1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$