

Farmlift 633
Farmlift 636
Farmlift 737
Farmlift 742
Farmlift 935
Stage IV
Telescopic Handler

SERVICE MANUAL

Part number 51546954
English
October 2018
© 2018 CNH Industrial Italia S.p.A. All Rights Reserved.

CASE II
AGRICULTURE



SERVICE MANUAL

FARMLIFT 633 STAGE IV 6 m (19.7 ft), 99 kW (133 Hp) [FNHZZP633NJKE00001
-]
FARMLIFT 636 STAGE IV 6 m (19.7 ft), 107 kW (145 Hp) [FNHZZK634NJKE00001
-]
FARMLIFT 737 STAGE IV 7 m (22.9 ft), 99 kW (133 Hp) [FNHZZP737NJKE00001
-]
FARMLIFT 742 STAGE IV 7 m (22.9 ft), 107 kW (145 Hp) [FNHZZK742NJKE00001
-]
FARMLIFT 935 STAGE IV 9 m (29.5 ft), 99 kW (133 Hp) [FNHZZP935NJKE00001
-]

Link Product / Engine

Product	Market Product	Engine
FARMLIFT 633 STAGE IV 6 m (19.7 ft), 99 kW (133 Hp) [FNHZZP633NJKE00001 -]	Europe	F4HFE413Z*B002
FARMLIFT 636 STAGE IV 6 m (19.7 ft), 107 kW (145 Hp) [FNHZZK634NJKE00001 -]	Europe	F4HFE4149*B001
FARMLIFT 737 STAGE IV 7 m (22.9 ft), 99 kW (133 Hp) [FNHZZP737NJKE00001 -]	Europe	F4HFE413Z*B002
FARMLIFT 742 STAGE IV 7 m (22.9 ft), 107 kW (145 Hp) [FNHZZK742NJKE00001 -]	Europe	F4HFE4149*B001
FARMLIFT 935 STAGE IV 9 m (29.5 ft), 99 kW (133 Hp) [FNHZZP935NJKE00001 -]	Europe	F4HFE413Z*B002

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.206] Fuel filters	10.3
[10.202] Air cleaners and lines	10.4
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.5
[10.400] Engine cooling system	10.6
[10.414] Fan and drive	10.7
Transmission	21
[21.113] Powershift transmission	21.1
[21.135] Powershift transmission external controls.....	21.2
[21.155] Powershift transmission internal components.....	21.3
[21.120] Gearbox	21.4
[21.109] Transmission cooler and lines.....	21.5
[21.700] Torque converter	21.6
Four-Wheel Drive (4WD) system	23
[23.314] Drive shaft.....	23.1
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
Rear axle system	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential	27.2
[27.120] Planetary and final drives	27.3

[27.124] Final drive hub, steering knuckles, and shafts	27.4
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
[33.220] Trailer brake hydraulic control.....	33.3
[33.204] Front axle brake	33.4
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.104] Fixed displacement pump.....	35.2
[35.106] Variable displacement pump	35.3
[35.359] Main control valve.....	35.4
[35.357] Pilot system	35.5
[35.128] Auxiliary hydraulic function control	35.6
[35.752] Hydraulic fan drive cooling system.....	35.7
[35.100] Main lift system.....	35.8
[35.355] Hydraulic hand control	35.9
[35.701] Front loader arm hydraulic system	35.10
[35.736] Boom hydraulic system	35.11
[35.734] Tool quick coupler hydraulic system	35.12
[35.740] Telescopic arm hydraulic system.....	35.13
Steering.....	41
[41.101] Steering control	41.1
[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders	41.3
Cab climate control	50
[50.200] Air conditioning	50.1
Electrical systems.....	55
[55.100] Harnesses and connectors.....	55.1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$