

WXI48 Wheeled Excavator

SERVICE MANUAL

Part number 48005353

English

April 2016

© 2016 CNH Industrial Italia S.p.A. All Rights Reserved.

CASE
CONSTRUCTION



SERVICE MANUAL

WX148

Link Product / Engine

| Product | Market Product | Engine |
|--|-----------------------|---------------|
| WX148 Wheeled excavator Mono Tier3 MY2013 - Nef 4 CYL Mech | Middle East Africa | F4GE9484 |
| WX148 Wheeled excavator Mono Tier3 MY2013 - Nef 4 CYL Mech | Europe | F4GE9484 |
| WX148 Wheeled excavator 2PB Tier3 MY2013 - Nef 4 CYL Mech | Europe | F4GE9484 |
| WX148 Wheeled excavator 2PB Tier3 MY2013 - Nef 4 CYL Mech | Asia Pacific | F4GE9484 |
| WX148 Wheeled excavator 2PB Tier3 MY2013 - Nef 4 CYL Mech | Middle East Africa | F4GE9484 |
| WX148 Wheeled excavator Mono Tier3 MY2013 - Nef 4 CYL Mech | Asia Pacific | F4GE9484 |

Contents

INTRODUCTION

| | |
|---|-----------|
| Engine | 10 |
| [10.202] Air cleaners and lines | 10.1 |
| [10.206] Fuel filters | 10.2 |
| [10.216] Fuel tanks | 10.3 |
| [10.218] Fuel injection system..... | 10.4 |
| [10.254] Intake and exhaust manifolds and muffler | 10.5 |
| [10.310] Aftercooler..... | 10.6 |
| [10.400] Engine cooling system | 10.7 |
| Transmission | 21 |
| [21.105] Powershift transmission lubrication system | 21.1 |
| [21.113] Powershift transmission | 21.2 |
| [21.135] Powershift transmission external controls..... | 21.3 |
| [21.155] Powershift transmission internal components..... | 21.4 |
| Four-Wheel Drive (4WD) system | 23 |
| [23.314] Drive shaft..... | 23.1 |
| Front axle system | 25 |
| [25.100] Powered front axle | 25.1 |
| [25.102] Front bevel gear set and differential | 25.2 |
| [25.108] Final drive hub, steering knuckles, and shafts | 25.3 |
| [25.122] Axle suspension control | 25.4 |
| Rear axle system | 27 |
| [27.100] Powered rear axle..... | 27.1 |
| [27.106] Rear bevel gear set and differential | 27.2 |
| [27.120] Planetary and final drives | 27.3 |
| Brakes and controls | 33 |

| | |
|---|-----------|
| [33.110] Parking brake or parking lock | 33.1 |
| [33.202] Hydraulic service brakes | 33.2 |
| Hydraulic systems..... | 35 |
| [35.000] Hydraulic systems..... | 35.1 |
| [35.106] Variable displacement pump | 35.2 |
| [35.300] Reservoir, cooler, and filters..... | 35.3 |
| [35.304] Combination pump units | 35.4 |
| [35.352] Hydraulic swing system | 35.5 |
| [35.353] Hydraulic travel system | 35.6 |
| [35.354] Hydraulic central joint | 35.7 |
| [35.357] Pilot system | 35.8 |
| [35.359] Main control valve..... | 35.9 |
| [35.360] Hammer and rotating bucket hydraulic system | 35.10 |
| [35.703] Stabilizer hydraulic system..... | 35.11 |
| [35.730] Positioning arm hydraulic system | 35.12 |
| [35.736] Boom hydraulic system | 35.13 |
| [35.737] Dipper hydraulic system..... | 35.14 |
| [35.738] Excavator and backhoe bucket hydraulic system..... | 35.15 |
| [35.741] Dozer blade cylinders | 35.16 |
| Frames and ballasting | 39 |
| [39.103] Swing ring assembly | 39.1 |
| [39.129] Stabilizers | 39.2 |
| [39.140] Ballasts and supports | 39.3 |
| Steering..... | 41 |
| [41.101] Steering control | 41.1 |
| [41.106] Tie rods..... | 41.2 |
| [41.200] Hydraulic control components..... | 41.3 |
| [41.216] Cylinders | 41.4 |

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$