

# SERVICE MANUAL

## PS2045 Pneumatic-Seeder

Part number 47918068  
English  
January 2015





# **SERVICE MANUAL**

**PS2045 Pneumatic**

# Contents

---

## INTRODUCTION

Machine completion and equipment.....	05
[05.102] Machine completion.....	05.1
Brakes and controls .....	33
[33.110] Parking brake or parking lock .....	33.1
[33.220] Trailer brake hydraulic control.....	33.2
Hydraulic systems.....	35
[35.162] Front hitch cylinders and lines .....	35.1
[35.353] Hydraulic travel system .....	35.2
[35.946] Frame positioning lifting.....	35.3
[35.744] Seeding and planting hydraulic circuits .....	35.4
[35.745] Vacuum system hydraulic circuit .....	35.5
Hitches, drawbars, and implement couplings.....	37
[37.100] Drawbars and towing hitches .....	37.1
Frames and ballasting .....	39
[39.100] Frame .....	39.1
[39.110] Drawbar and hitch assembly .....	39.2
[39.140] Ballasts and supports .....	39.3
Wheels .....	44
[44.530] Carrying and transport wheels .....	44.1
Electrical systems .....	55
[55.100] Harnesses and connectors.....	55.1
[55.640] Electronic modules.....	55.2
[55.036] Hydraulic system control .....	55.3
[55.517] Cab seeding controls.....	55.4
[55.516] Seeding control system .....	55.5

[55.404] External lighting .....	55.6
<b>Metering system .....</b>	<b>61</b>
[61.904] Product metering .....	61.1
<b>Soil preparation/Finishing .....</b>	<b>75</b>
[75.200] Ground-engaging components.....	75.1
<b>Seeding .....</b>	<b>77</b>
[77.100] Product handling and delivery drive system .....	77.1
[77.105] Seeding tool .....	77.2
[77.904] Air distribution system.....	77.3
<b>Platform, cab, bodywork, and decals.....</b>	<b>90</b>
[90.118] Protections and footboards.....	90.1



It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$