580N
580SN WT
580SN
590SN
Tier 4B (final)
Tractor Loader Backhoe

SERVICE MANUAL

Part number 47830958

Ist edition English

August 2015





SERVICE MANUAL

580N FOUR-WHEEL DRIVE (4WD) TIER 4B (FINAL), 580N TWO-WHEEL DRIVE (2WD) TIER 4B (FINAL), 580SN FOUR-WHEEL DRIVE (4WD) TIER 4B (FINAL), 580SN TWO-WHEEL DRIVE (2WD) TIER 4B (FINAL), 580SN WT TIER 4B (FINAL), 590SN FOUR-WHEEL DRIVE (4WD) TIER 4B (FINAL), 590SN TWO-WHEEL DRIVE (2WD) TIER 4B (FINAL)

Link Product / Engine

Product	Market Product	Engine
580N TWO-WHEEL DRIVE (2WD)	North America	F5BFL413A*B007
TIER 4B (FINAL)		
580N FOUR-WHEEL DRIVE	North America	F5BFL413A*B007
(4WD) TIER 4B (FINAL)		
580SN TWO-WHEEL DRIVE	North America	F5BFL413A*B007
(2WD) TIER 4B (FINAL)		
580SN FOUR-WHEEL DRIVE	North America	F5BFL413A*B007
(4WD) TIER 4B (FINAL)		
580SN WT TIER 4B (FINAL)	North America	F5BFL413A*B007
590SN TWO-WHEEL DRIVE	North America	F5BFL413A*B007
(2WD) TIER 4B (FINAL)		
590SN FOUR-WHEEL DRIVE	North America	F5BFL413A*B007
(4WD) TIER 4B (FINAL)		

Contents

INTRODUCTION

	Ingine	10
	[10.001] Engine and crankcase	10.1
	[10.202] Air cleaners and lines	10.2
	[10.206] Fuel filters	10.3
	[10.216] Fuel tanks	10.4
	[10.218] Fuel injection system	10.5
	[10.304] Engine lubrication system	10.6
	[10.400] Engine cooling system	10.7
	[10.414] Fan and drive	10.8
	[10.500] Selective Catalytic Reduction (SCR) exhaust treatment	10.9
I	ransmission	21
	[21.112] Power shuttle transmission	21.1
	[21.113] Powershift transmission	21.2
	[21.134] Power shuttle transmission external controls	21.3
	[21.135] Powershift transmission external controls	21.4
	[21.154] Power shuttle transmission internal components	21.5
	[21.155] Powershift transmission internal components	21.6
F	ront axle system	25
	[25.100] Powered front axle	25.1
	[25.102] Front bevel gear set and differential	25.2
	[25.108] Final drive hub, steering knuckles, and shafts	25.3
	[25.400] Non-powered front axle	25.4
F	Rear axle system	27
	[27.100] Powered rear axle	
	[27.106] Rear bevel gear set and differential	27.2

	[27.120] Planetary and final drives	. 27.3
E	Brakes and controls	. 33
	[33.110] Parking brake or parking lock	. 33.1
	[33.202] Hydraulic service brakes	. 33.2
H	Hydraulic systems	. 35
	[35.000] Hydraulic systems	. 35.1
	[35.102] Pump control valves	. 35.2
	[35.104] Fixed displacement pump	. 35.3
	[35.106] Variable displacement pump	. 35.4
	[35.204] Remote control valves	. 35.5
	[35.300] Reservoir, cooler, and filters	. 35.6
	[35.350] Safety and main relief valves	. 35.7
	[35.359] Main control valve	. 35.8
	[35.525] Auxiliary hydraulic valves and lines	. 35.9
	[35.703] Stabilizer hydraulic system	35.10
	[35.723] Front loader bucket hydraulic system	35.11
	[35.726] Excavator and backhoe hydraulic controls	35.12
	[35.736] Boom hydraulic system	35.13
	[35.737] Dipper hydraulic system	35.14
	[35.738] Excavator and backhoe bucket hydraulic system	35.15
	[35.739] Swing arm hydraulic system	35.16
	[35.740] Telescopic arm hydraulic system	35.17
F	rames and ballasting	. 39
	[39.100] Frame	. 39.1
	[39.129] Stabilizers	. 39.2
S	Steering	. 41
	[41.101] Steering control	. 41.1
	[41 200] Hydraulic control components	41 2

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$