



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4




1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

# CX290 Crawler Excavators

## Table of contents

DIVISION/SECTION	SECTION No.	REFERENCE No.
<b>1 GENERAL INFORMATION</b>		
Safety, general information and standard torque data .....	1001	9-53360
General specifications and special torque setting.....	1002	9-53220
<b>2 ENGINE</b>		
Removal and installation of the engine .....	2000	9-43820GB
Radiator and oil-cooler .....	2001	9-44490GB
Engine specifications .....	*	
Disassembly and assembly of the engine.....	*	
<b>3 FUEL SYSTEM</b>		
Fuel tank .....	3001	7-27970GB
Fuel engine system.....	*	
<b>4 ELECTRICAL SYSTEM</b>		
Electrical system, electrical and electronic troubleshooting .....	4001	9-53380
Inspection and maintenance of batteries and connecting a booster battery....	4002	9-43460GB
Main and engine electronic control boxes .....	4003	9-43450GB
<b>5 UNDERCARRIAGE</b>		
Removal and installation of tracks .....	5001	7-27750GB
Rollers .....	5003	9-42920GB
Sprocket .....	5004	9-36890GB
Idler wheel and tension shock absorber .....	5005	9-43000GB
<b>6 DRIVE TRAIN</b>		
Drive motor and final drive transmission removal and installation .....	6001	9-43140GB
Swing reduction gear, removal and installation .....	6003	9-44010GB
Swing reduction gear, disassembly and assembly.....	6004	9-43220GB
Travel reduction gear assembly and disassembly.....	6005	9-43150GB
<b>7 UNDERCARRIAGE HYDRAULICS</b>		
<b>8 UPPERSTRUCTURE HYDRAULICS</b>		
Depressurising and decontaminating the hydraulic system, use of the vacuum pump and bleeding the components .....	8000	9-44030GB
Specifications, troubleshooting, checks and hydraulic pressure settings.....	8001	9-53390
Hydraulic reservoir removal and installation .....	8002	7-27990GB
Main and pilot pumps, removal and installation .....	8003	9-44050GB
Main hydraulic control valve, removal and installation .....	8004	9-44410GB
Attachment cylinders, removal and installation .....	8005	7-27791GB
Hydraulic swivel, removal and installation.....	8006	7-27811GB
Pilot blocs, removal and installation .....	8007	9-35590
Swing motor, removal and installation.....	8008	9-44020GB
Free swing disassembly and assembly .....	8009	9-35530
Main hydraulic pump, disassembly and assembly .....	8010	9-35491GB
Main hydraulic control valve, disassembly and assembly .....	8011	9-43550GB
Attachment cylinders, disassembly and assembly.....	8012	9-44420GB
Hand control levers, disassembly and assembly .....	8013	7-28110GB
Foot control levers, disassembly and assembly .....	8014	7-28210GB
Six-solenoid valves, disassembly and assembly.....	8015	9-43360GB
Caution valve, disassembly and assembly.....	8016	7-27942GB
Safety valve.....	8017	7-29631GB
Hydraulic swivel, disassembly and assembly.....	8018	7-28080GB
Swing motor, disassembly and assembly .....	8019	9-43440GB
Hydraulic functions.....	8020	9-53400
Travel hydraulic motor, disassembly and assembly.....	8021	9-43160GB

DIVISION/SECTION	SECTION No.	REFERENCE No.
<b>9 UPPERSTRUCTURE</b>		
Upperstructure, turntable and counterweight.....	9002	9-43760GB
Boom, dipper and bucket .....	9003	7-27961GB
Seat and seat belt .....	9004	9-40960GB
Cab and cab equipment.....	9005	9-43750GB
Air conditioner troubleshooting and system checks .....	9006	9-88730GB
Air conditioning unit disassembly and assembly .....	9007	██████████
Air conditioning servicing .....	9008	██████████
Air conditioning components.....	9009	██████████
Attachment reinforcement procedures .....	9012	9-43910
Large format hydraulic and electrical schematics .....	Pocket	9-42670

\* Consult the Engine Service Manual

██████████ Sections to be distributed at a later date

NOTE: Case Company reserves the right to make changes in the specification and design of the machine without prior notice and without incurring any obligation to modify units previously sold.

The description of the models shown in this manual has been made in accordance with the technical specifications known as of the date of design of this document.

**REVISION No. 1**  
**Crawler excavators**  
**CX290**  
**Service manual Cre 9-53580**

**Revision contents:**

9-53581	Identification Decal .....	New Decal
9-53431	Table of Contents.....	New Table of Contents
9-88870GB	Section 9006 - Air Conditioner Troubleshooting and System Checks.....	New Section

**NOTE:** *Keep this revision page with the first pages in your binder for reference purposes. If you have several revisions to insert at the same time, start with the oldest, then the next oldest, and so on.*



It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$