

FARMALL® I 10A
FARMALL® I 20A
FARMALL® I 30A
FARMALL® I 40A
Tier 4B (final)
Tractor

PIN CT00001M and above

SERVICE MANUAL

Part number 47924636

1st edition English

December 2015

CASE II
AGRICULTURE



SERVICE MANUAL

Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and cab. , Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and cab. , Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and cab. , Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and cab.

Link Product / Engine

Product	Market Product	Engine
Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413U*B001
Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413U*B001
Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413U*B001
Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413U*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413T*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413T*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413T*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413T*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413S*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413S*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413S*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413S*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413R*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413R*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413R*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413R*B001

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.206] Fuel filters	10.3
[10.216] Fuel tanks	10.4
[10.254] Intake and exhaust manifolds and muffler	10.5
[10.310] Aftercooler.....	10.6
[10.400] Engine cooling system	10.7
[10.414] Fan and drive	10.8
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.9
Clutch	18
[18.100] Clutch mechanical release control	18.1
[18.110] Clutch and components	18.2
[18.112] Slip clutch or flywheel damper	18.3
Transmission	21
[21.109] Transmission cooler and lines.....	21.1
[21.112] Power shuttle transmission.....	21.2
[21.114] Mechanical transmission	21.3
[21.134] Power shuttle transmission external controls	21.4
[21.154] Power shuttle transmission internal components	21.5
[21.160] Creeper	21.6
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1
[23.304] Four-Wheel Drive (4WD) gearbox	23.2
[23.314] Drive shaft.....	23.3

Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.400] Non-powered front axle	25.4
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
[27.120] Planetary and final drives	27.3
Power Take-Off (PTO).....	31
[31.114] Two-speed rear Power Take-Off (PTO)	31.1
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.116] Three-point hitch cylinder	35.4
[35.204] Remote control valves	35.5
[35.304] Combination pump units	35.6
Hitches, drawbars, and implement couplings.....	37
[37.110] Rear three-point hitch	37.1
Steering.....	41
[41.101] Steering control	41.1
[41.106] Tie rods.....	41.2
[41.206] Pump.....	41.3
[41.216] Cylinders	41.4

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$