

Rowtrac™ 370 / 420 / 470 / 500
Steiger® 370 / 420 / 470 / 500 / 540 / 580 / 620
Quadtrac® 470 / 500 / 540 / 580 / 620
Tier 4B (final)
Tractor
PIN ZEF300001 and above

SERVICE MANUAL

Part number 47680525

1st edition English

March 2014



Link Product / Engine

| Product | Market Product | Engine |
|---|----------------|----------------|
| null NA model [ZEF300001 -] | North America | F3HFE613D*B001 |
| null NA model [ZEF300001 -] | North America | F3DFE613J*B001 |
| null NA scraper model [ZEF300001 -] | North America | F3DFE613J*B001 |
| null NA model [ZEF300001 -] | North America | F3DFE613G*B001 |
| null NA scraper model [ZEF300001 -] | North America | F3DFE613G*B001 |
| null NA model [ZEF300001 -] | North America | F3DFE613F*B001 |
| null NA model [ZEF300001 -] | North America | F2CFE614A*B |
| null NA model [ZEF300001 -] | North America | F3HFE613G*B001 |
| null NA model [ZEF300001 -] | North America | F3HFE613D*B001 |
| null NA model [ZEF300001 -] | North America | F3HFE613B*B001 |
| null NA standard wheeled [ZEF300001 -] | North America | F2CFE614A*B |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F2CFE614A*B |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F3HFE613G*B001 |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F3HFE613D*B001 |
| null NA Wheeled scraper [ZEF300001 -] | North America | F3HFE613D*B001 |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F3HFE613B*B001 |
| null NA wheeled scraper [ZEF300001 -] | North America | F3HFE613B*B001 |
| null NA model [ZEF300001 -] | North America | F3HFE613B*B001 |
| null NA scraper model [ZEF300001 -] | North America | F3HFE613B*B001 |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F3DFE613J*B001 |
| null NA wheeled scraper [ZEF300001 -] | North America | F3DFE613J*B001 |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F3DFE613G*B001 |
| null NA wheeled scraper [ZEF300001 -] | North America | F3DFE613G*B001 |
| null NA heavy duty wheeled [ZEF300001 -] | North America | F3DFE613F*B001 |
| null NA wheeled scraper [ZEF300001 -] | North America | F3DFE613F*B001 |

Contents

INTRODUCTION

| | |
|---|-----------|
| Engine | 10 |
| [10.001] Engine and crankcase | 10.1 |
| [10.216] Fuel tanks | 10.2 |
| [10.202] Air cleaners and lines | 10.3 |
| [10.310] Aftercooler..... | 10.4 |
| [10.400] Engine cooling system | 10.5 |
| [10.414] Fan and drive | 10.6 |
| [10.500] Selective Catalytic Reduction (SCR) exhaust treatment..... | 10.7 |
| Transmission | 21 |
| [21.113] Powershift transmission | 21.1 |
| [21.135] Powershift transmission external controls..... | 21.2 |
| [21.145] Gearbox internal components..... | 21.3 |
| [21.155] Powershift transmission internal components..... | 21.4 |
| Front axle system | 25 |
| [25.100] Powered front axle | 25.1 |
| [25.102] Front bevel gear set and differential | 25.2 |
| [25.310] Final drives | 25.3 |
| [25.500] Front axle track yoke assembly | 25.4 |
| Rear axle system | 27 |
| [27.100] Powered rear axle..... | 27.1 |
| [27.106] Rear bevel gear set and differential | 27.2 |
| [27.120] Planetary and final drives | 27.3 |
| [27.610] Rear axle track yoke assembly | 27.4 |
| Power Take-Off (PTO) | 31 |
| [31.104] Rear electro-hydraulic control..... | 31.1 |

| | |
|--|-----------|
| [31.110] One-speed rear Power Take-Off (PTO) | 31.2 |
| [31.220] Gearbox | 31.3 |
| Brakes and controls | 33 |
| [33.110] Parking brake or parking lock | 33.1 |
| [33.202] Hydraulic service brakes | 33.2 |
| Hydraulic systems..... | 35 |
| [35.000] Hydraulic systems..... | 35.1 |
| [35.102] Pump control valves..... | 35.2 |
| [35.105] Charge pump..... | 35.3 |
| [35.106] Variable displacement pump | 35.4 |
| [35.204] Remote control valves | 35.5 |
| [35.220] Auxiliary hydraulic pump and lines | 35.6 |
| [35.300] Reservoir, cooler, and filters..... | 35.7 |
| [35.304] Combination pump units | 35.8 |
| [35.600] High flow hydraulics | 35.9 |
| Hitches, drawbars, and implement couplings..... | 37 |
| [37.100] Drawbars and towing hitches | 37.1 |
| Frames and ballasting | 39 |
| [39.100] Frame | 39.1 |
| [39.110] Drawbar and hitch assembly | 39.2 |
| Steering..... | 41 |
| [41.101] Steering control | 41.1 |
| [41.200] Hydraulic control components..... | 41.2 |
| [41.206] Pump | 41.3 |
| Wheels | 44 |
| [44.511] Front wheels..... | 44.1 |
| [44.520] Rear wheels..... | 44.2 |
| Tracks and track suspension | 48 |

| | |
|---|-----------|
| [48.100] Tracks | 48.1 |
| [48.130] Track frame and driving wheels | 48.2 |
| [48.134] Track tension units | 48.3 |
| [48.138] Track rollers | 48.4 |
| Cab climate control | 50 |
| [50.104] Ventilation | 50.1 |
| [50.200] Air conditioning | 50.2 |
| [50.300] Cab pressurizing system | 50.3 |
| Electrical systems | 55 |
| [55.000] Electrical system | 55.1 |
| [55.100] Harnesses and connectors | 55.2 |
| [55.301] Alternator | 55.3 |
| [55.302] Battery | 55.4 |
| [55.010] Fuel injection system | 55.5 |
| [55.014] Engine intake and exhaust system | 55.6 |
| [55.024] Transmission control system | 55.7 |
| [55.045] Front axle control system | 55.8 |
| [55.046] Rear axle control system | 55.9 |
| [55.048] Rear Power Take-Off (PTO) control system | 55.10 |
| [55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system | 55.11 |
| [55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls | 55.12 |
| [55.404] External lighting | 55.13 |
| [55.522] Cab Power Take-Off (PTO) controls | 55.14 |
| [55.640] Electronic modules | 55.15 |
| [55.035] Remote control valve electric control | 55.16 |
| [55.130] Rear three-point hitch electronic control system | 55.17 |
| [55.988] Selective Catalytic Reduction (SCR) electrical system | 55.18 |
| [55.DTC] FAULT CODES | 55.19 |

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$