## **FORD**


#### **Service Manual**



Tractors TW5, TW15, TW25, TW35 8530, 8630, 8730, 8830

Part 1 – Engine Systems Part 2 – Fuel Systems

Vol. 1



#### **CONTENTS**

| Part 1 – Engine Systems           | Vol. 1 |
|-----------------------------------|--------|
| Part 2 – Fuel Systems             | Vol. 1 |
| Part 3 – Electrical Systems       | Vol. 2 |
| Part 4 – Clutches                 | Vol. 2 |
| Part 5 – Transmission Systems     | Vol. 3 |
| Part 6 – Power Take-Off           | Vol. 4 |
| Part 7 – Rear Axle & Brakes       | Vol. 4 |
| Part 8 – Hydraulic Systems        | Vol. 4 |
| Part 9 – Steering Systems         | Vol. 5 |
| Part 10 – Front Axle              | Vol. 5 |
| Part 11 – Safety Cabs & Platforms | Vol. 6 |
| Part 12 – Separating the Tractor  | Vol. 6 |
| Part 13 – Accessories & General   | Vol. 6 |

#### PART 1 ENGINE SYSTEMS

# Chapter 1 ENGINE AND LUBRICATION SYSTEM

| Section |   | Page |
|---------|---|------|
| Α.      | DESCRIPTION AND OPERATION   | 1    |
| В.      | CYLINDER HEAD, VALVES AND RELATED PARTS                               | 4    |
| C.      | ENGINE FRONT COVER AND TIMING GEARS                                   | 20   |
| D.      | OIL PAN AND OIL PUMP  | 26   |
| E.      | CONNECTING RODS, BEARINGS, PISTONS, RINGS, CYLINDER BLOCK AND SLEEVES | 32   |
| F.      | MAIN BEARINGS, FLYWHEEL AND CRANKSHAFT                                | 46   |
| G.      | CAMSHAFT  | 53   |
| Н.      | ENGINE COMPRESSION TEST   | 55   |

## Chapter 2 TURBOCHARGER

| Section |                           | Page |  |
|---------|---------------------------|------|--|
| Α.      | DESCRIPTION AND OPERATION | 1    |  |
| В.      | TURBOCHARGER OVERHAUL     | 4    |  |
| C       | TROUBLE SHOOTING          | 14   |  |

#### Chapter 3 INTERCOOLER

| Section |                                     | Page |
|---------|-------------------------------------|------|
| Α.      | DESCRIPTION AND OPERATION           | 1    |
| В.      | INTERCOOLER OVERHAUL                | 2    |
| C.      | HEAT EXCHANGER SERVICE AND OVERHAUL | 8    |

# **Chapter 4**COOLING SYSTEM

| Section |                                | Page |
|---------|--------------------------------|------|
| A.      | DESCRIPTION AND OPERATION      | 1    |
| В.      | RADIATOR AND THERMOSTATS       | 3    |
| C.      | WATER PUMP                     | 5    |
| D.      | COOLING FAN AND DRIVE ASSEMBLY | 8    |

#### **Chapter 5**TROUBLE SHOOTING

| Section |                  | Page |
|---------|------------------|------|
| Α.      | TROUBLE SHOOTING | 1    |

## Chapter 6 SPECIFICATIONS AND SPECIAL TOOLS

| Section   |                | Page |
|-----------|----------------|------|
| <b>A.</b> | SPECIFICATIONS | 1    |
| В.        | SPECIAL TOOLS  | 12   |

#### **FOREWORD**

This Service Manual provides information for the correct servicing and overhaul of the Ford TW Series and 30 Series 6-cylinder agricultural tractors and is an essential publication for all service personnel carrying out repairs or maintenance on these tractors. We recommend that this manual be available for reference at all times.

The Service Manual consists of thirteen Parts contained in six volumes. A Table of Contents is included in each volume which lists all thirteen Parts and the volume where each can be found.

All Parts are subdivided into Chapters which convey information on general operating principles, detailed inspection and overhaul procedures and, where applicable, specifics on troubleshooting, special tools and specifications. Any reference in this manual to right, left, rear, front, top or bottom is as viewed from the operator's seat.

The information contained herein was correct at the time of going to print but Ford New Holland, Inc. policy is one of continuous improvement and the right to change prices, specifications, equipment or design at any time without notice is reserved. All data in this manual is subject to production variations, and the illustrations do not necessarily depict tractors to standard build specifications.

It's a preview. You can download the full file by clicking the link below.

# https://shopservicemanual.com/

Service Manuals from 2\$