

# Workshop Manual

# ZX 225USLC-6 225USRLC-6 Hydraulic Excavator

ZX225USLC-6 • 225USRLC-6 HYDRAULIC EXCAVATOR WORKSHOP MANUAL

WDFB50-EN-00

 **Hitachi Construction Machinery Co., Ltd.**

URL:<http://www.hitachi-c-m.com>



---

---

# SECTION 1

# GENERAL

## CONTENTS

### **Group 1 Precautions for Disassembling and Assembling**

Precautions for Disassembling and Assembling .....	W1-1-1-1
--	----------

### **Group 2 Tightening**

Tightening Bolts and Nuts .....	W1-2-1-1
Piping Joint .....	W1-2-1-4

### **Group 3 Painting**

Painting .....	W1-3-1-1
----------------	----------

### **Group 4 Bleeding Air**

Bleeding Air from Hydraulic System .....	W1-4-1-1
Bleeding Air from Fuel System .....	W1-4-1-2
Air Bleeding from the Diesel Exhaust Fluid Defrosting Piping .....	W1-4-1-4

### **Group 5 Preparation**

Preparation before Inspection and Maintenance .....	W1-5-1-1
Hydraulic Circuit Pressure Release Procedure .....	W1-5-1-3
Pressure Release from Hydraulic Oil Tank .....	W1-5-1-4
Pressure Release from Expansion Tank .....	W1-5-1-5

---

(Blank)

---

---

## SECTION 2

# MAINTENANCE STANDARD

### CONTENTS

#### Group 1 Upperstructure

Pump Device .....	W2-1-1-1
Swing Motor .....	W2-1-2-1

#### Group 2 Undercarriage

Travel Motor .....	W2-2-1-1
Sprocket .....	W2-2-1-3
Front Idler .....	W2-2-2-1
Upper Roller .....	W2-2-3-1
Lower Roller .....	W2-2-3-2
Track.....	W2-2-4-1

#### Group 3 Front Attachment

Pin and Bushing.....	W2-3-1-1
Side Cutter (2014503, 2014504) .....	W2-3-1-3
Point (4427919) .....	W2-3-1-4
Standard Dimensions for Arm and Bucket Connection .....	W2-3-1-5
Standard Dimensions for Arm and Boom Connection .....	W2-3-1-6
Cylinder .....	W2-3-2-1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$