
## **SERVICE MANUAL**

### E215C E245C

**Crawler Excavators** 



Print no. 47399290A I<sup>st</sup> Edition English 07/12





#### Read this manual before operating the machine

Most accidents occurring during work are due to non-observance of simple safety norms and elementary precautions.

Many accidents can be avoided if the causes are known and opportune cautions taken beforehand.

There is no device or protection, no matter how advanced, that may prove so effective at avoiding accidents as a careful and attentive behaviour.



Ensure that the attachment is safely resting onto the ground before repairing, adjusting or servicing machines fitted with hydraulically, mechanically or cable controlled attachments (such as, excavators, loaders, dozers, scrapers, etc.). Should it be necessary to partially or fully raise the hydraulically, mechanically or cable controlled attachment to gain access to certain items, make sure the attachment is adequately retained in the raised position by means other than the hydraulic lift cylinders, cables and/or mechanical devices used for controlling it.

#### TO THE READER

- This manual is written for an experienced technician to provide technical information needed to maintain and repair this machine.
  - Be sure to thoroughly read this manual for correct information concerning the service procedures.
- If you have any questions or comments, or if you found any errors regarding the contents of this manual, please contact:

NEW HOLLAND KOBELCO CONSTRUCTION MACHINERY S.p.A. Strada Settimo, 323 San Mauro Torinese (TO) 10099 ITALIA PRODUCT SUPPORT Fax. ++39 011 0077357

#### **ADDITIONAL REFERENCES**

- Please refer to the materials listed below in addition to this service manual:
  - Operator's Manual
  - Service Parts Catalogue

#### **COMPLETE SERVICE MANUAL**

- The complete Service Manual consists of two distinct volumes:
  - Service Manual "Crawler Excavators"
  - Service Manual "Engine"

The two distinct volumes of the complete Service Manual can be identified through their print number as stated below:


VOLUME	PRINT NUMBER	
Service Manual "Crawler Excavators"	47399290A	
Service Manual "Engine"	84250493	

- The Service Manual "Crawler Excavators" consists of five parts:
  - "General Safety Information"
  - "Operational Principle"
  - "Operational Performance Test"
  - "Troubleshouting"
  - "Repair Instructions"

- The "General Safety Information" part includes the recommended procedures that, if followed, can avoid the risk of accident for operator and for staff related to the work and maintenance machine operations.
- The "Operational Principle" part includes the technical information concerning the operation of main devices and systems.
- The "Operational Performance Test" part includes the information needed to carry out the machine operational performance test.
- The "Troubleshooting" part includes the technical information needed for troubleshooting and malfunction detection.
- The "Repair Instructions" part includes information needed for maintenance and repair of the machine, tools and devices needed for maintenance and repair, maintenance standards, removal/installation and assembly/disassembly procedures.

#### **PAGE NUMBER**

• Each page has a number, located on the central lower side of the page. Each page number contains the following information:



#### **SYMBOLS**

In this manual, the following safety alert symbol and signal words are used to alert the reader to the potential for personal injury or machine damage.



This is the safety alert symbol.

When you see this symbol, be alert to the potential for personal injury.

Never fail to follow the safety instructions prescribed along with the safety alert symbol.

The safety alert symbol is also used to draw attentio in to component/part weights.

To avoid injury and damage, be sure to use appropriate lifting techniques and equipment when lifting heavy parts.

#### **UNITS USED**

SI Units (International System of Units) are used in this manual.

MKSA system units and English units are also indicated in parentheses just behinds SI units.

Example: 24.5 MPa (250 kgf/cm<sup>2</sup>)

A table for conversion from SI units to other system units is shown below for reference purposes.

Quantity	To convert from (SI)	Into (Others)	Multiply by	
Lenght	mm	in	0.03937	
	mm	ft	0.003281	
Volume	L	US gal	0.2642	
	L	US qt	1.057	
	m <sup>3</sup>	yd <sup>3</sup>	1.308	
Mass	kg	lb	2.205	
Force	N	kgf	0.10197	
	N	lbf	0.2248	
Torque	N.m	kgf.m	0.10197	
	N.m	lbf.ft	0.7375	

Quantity	To convert from (SI)	Into (Others)	Multiply by	
Pressure	MPa	kgf/cm <sup>2</sup>	10.197	
	MPa	psi	145.0	
Power	kW	CV-PS	1.360	
	kW	HP	1.341	
Temperature	°C	°F	°C x 1.8 + 32	
Velocity	km/h	mph	0.6214	
	min <sup>-1</sup>	rpm	1.0	
Flow rate	L/min	US gpm	0.2642	
	mL/rev	cc/rev	1.0	
	cm <sup>3</sup> /rev	in <sup>3</sup> /rev	0.061	

INDEX E215C-E245C

#### **MANUAL INDEX**

lack	GENERA	L SAFETY INFORMATION	Page
	Section 2	SAFETY INFORMATIONSAFETY PRECAUTIONSSAFETY DECALS	\$2
	OPERATI	ONAL PRINCIPLE	
	Section 1 Group 1	GENERAL INFORMATION Specifications	T1-1
	Section 2	SYSTEM	
	Group 1	Mechatro Control System	
	Group 2 Group 3	Hydraulic SystemElectrical System	
	Section 3	COMPONENT OPERATION	
£ . \$	Group 1	Hydraulic Pump Assy	
7.1	Group 2 Group 3	Pilot Valve Control Valve	
77.5	Group 4	Swing Device	
	Group 5	Travel Device	
	Group 6 Group 7	Swivel Joint	
	Group 8	Air Conditioner system	
	Group 9	Electrical Equipment	
	OPERATI	ONAL PERFORMANCE TEST	
	Section 4	OPERATIONAL PERFORMANCE TEST	
	Group 1	Introduction	
	Group 2 Group 3	Standard Performances Test Procedures	
	Group 4	Mechatro Controller	
	TROUBL	ESHOOTING	
	Section 5	TROUBLESHOOTING	
	Group 1	Troubleshooting (by error codes)	
	Group 2	Troubleshooting (by trouble)	T5-2

It's a preview. You can download the full file by clicking the link below.

# https://shopservicemanual.com/

Service Manuals from 2\$