

## JS 100 Series Tracked Excavators T4i

[Section 1 - General Information](#)

[Section 2 - Operator's Manual](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section J - Track & Running Gear](#)

[Section K - Engine](#)



Publication No.  
**9813/2200-4**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class  
Customer Support



## General Information

Service Manual - JS 100 Series Tracked Excavators T4i

[Section 1 - General Information](#)

[Section 2 - Operator's Manual](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section J - Track & Running Gear](#)

[Section K - Engine](#)



Publication No.  
**9813/2200-04**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class  
Customer Support





# Section 1 - General Information

---

| <b>Contents</b>                                    | <b>Page No.</b> |
|--|-----------------|
| <b>Introduction</b>                                |                 |
| Identifying Your Machine .....                     | 1-1             |
| <b>Safety</b>                                      |                 |
| Introduction .....                                 | 1-3             |
| <b>Use</b>   |                 |
| Introduction .....                                 | 1-5             |
| Scope .....  | 1-6             |
| Format .....                                       | 1-7             |
| Left Side, Right Side .....                        | 1-8             |
| Hydraulic Schematic Codes .....                    | 1-9             |
| <b>Routine Maintenance</b>                         |                 |
| Maintenance Schedules .....                        | 1-11            |
| <b>General Procedures</b>                          |                 |
| Introduction .....                                 | 1-13            |
| Parking the Machine and Making it Safe .....       | 1-14            |
| Venting the Hydraulic Pressure .....               | 1-15            |
| Connecting/Disconnecting Hydraulic Hoses .....     | 1-16            |
| Battery Disconnection/Connection .....             | 1-17            |
| Removing and Replacing Components .....            | 1-18            |
| Battery Charging System Precautions .....          | 1-19            |
| Gas Hydraulic Bladder Accumulators .....           | 1-20            |
| <b>Service Consumables</b>                         |                 |
| Introduction .....                                 | 1-23            |
| Sealing and Retaining Compounds .....              | 1-24            |
| <b>Torque Settings</b>                             |                 |
| Introduction .....                                 | 1-25            |
| Zinc Plated Fasteners and Dacromet Fasteners ..... | 1-26            |
| Hydraulic Connections .....                        | 1-30            |
| 'Positional Type' Hydraulic Adaptors .....         | 1-34            |
| <b>Service Tools</b>                               |                 |
| Numerical List .....                               | 1-35            |
| Tool Detail Reference .....                        | 1-38            |

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$