

JS200, JS210, JS220, JS240, JS260

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section B - Body & Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section J - Track and Running Gear](#)

[Section K - Engine](#)



Publication No.
9803/6510-03



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Service, World Parts Centre, Beamhurst, Uttoxeter, Staffordshire, ST14 5PA, England. Tel +44 1889 590312 Fax +44 1889 593377

World Class
Customer Support

General Information

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section B - Body & Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section J - Track and Running Gear](#)

[Section K - Engine](#)



Publication No.
9803/6510-03



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Service, World Parts Centre, Beamhurst, Uttoxeter, Staffordshire, ST14 5PA, England. Tel +44 1889 590312 Fax +44 1889 593377

World Class
Customer Support



Page left intentionally blank

Contents	Page No.
Introduction	
About this Publication	1 - 1
Schematic Codes	1 - 2
Colour Codes	1 - 2
Identifying your Machine	
Identifying Your Machine	1 - 3
Data Plate	1 - 3
Typical Product Identification Number (PIN)	1 - 3
Typical Engine Identification Number	1 - 4
Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	1 - 5
Introduction	1 - 5
Bolts and Screws	1 - 5
Hydraulic Connections	1 - 9
'O' Ring Face Seal System	1 - 9
'Torque Stop' Hose System	1 - 12
Service Tools	
Numerical List Section B - Body and Framework	1 - 13
Tool Detail Reference Section B - Body and Framework	1 - 14
Numerical List Section C - Electrics	1 - 17
Tool Detail Reference Section C - Electrics	1 - 18
Numerical List Section E- Hydraulics	1 - 20
Tool Detail Reference Section E- Hydraulics	1 - 22
Inserting seal ring and correction jig	1 - 29
Jig for pulling out, press-fitting bushing	1 - 30
Jig for press-fitting wiper ring	1 - 30
Jig for inserting cylinder head	1 - 30
Seal Ring and Connector Jig	1 - 30
Bush Removal Jig	1 - 30
Bush Fitting Jig	1 - 31
Wiper Ring Fitting Jig	1 - 31
Wiper Ring Fitting Jig	1 - 31
Numerical List Section F - Transmission	1 - 32
Tool Detail Reference Section F - Transmission	1 - 33
Service Consumables	
Sealing and Retaining Compounds	1 - 36



Section 1 - General information

Contents

Page No.

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$