



NEW HOLLAND

BACKHOE LOADER

B95
B95TC
B95LR
B110
B115

SERVICE MANUAL

60367230 NA

Issued 04-2006

 **NEW HOLLAND**

www.newhollandconstruction.com



SERVICE MANUAL

BACKHOE LOADER

B95

B95TC

B95LR

B110

B115

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer.

This unit first became available 01-2006			
REVISION HISTORY			
Issue	Issue Date	Applicable Machines	Remarks
First Edition	04-2006	B95, B95TC, B95LR, B110, B115	60367230 NA

TO READER

This manual has been printed for a kilful engineer to supply necessary technical information to carry out service operations on this machine.

CNH AMERICA LLC
245 E North Avenue
Carol Stream, Il 60188 U.S.A.

Read carefully this manual to collect correct information relevant to repair procedures.

For any question or remark, or in case of any error relevant the contents of this manual, please contact:

REFERENCE

Beyond this Service Manual, also refer to documents hereunder listed:

- Operator's Manual
- Parts Catalogue

COMPLETE HANDBOOK FOR INSTRUCTIONS AND REPAIRS

The complete Service Manual consists of two volumes:

- B95 - B95TC - B95LR - B110- B115
Service Manual "LOADER BACKHOE"
- B95 - B95TC - B95LR - B110- B115
Service Manual "Engine"

The Service Manuals for "Loader backhoe" and "Engine" contain the necessary technical information to carry out service and repair on machine and on engine, necessary tools to carry out those operations and information on service standard, on procedures for connection, disconnection, disassembly and assembly of parts.

The complete Service Manual which covers the loader backhoe models B95 - B95TC - B95LR - B110 - B115 consists of the following volumes, which can be identified through their print no. as stated below:

VOLUME	MACHINE TYPE	PRINT NUMBER
Service Manual - "Loader backhoe"	B95 - B95TC - B95LR - B110 - B115	603.67.230
Service Manual - "Engine"	B95 - B95TC - B95LR - B110 - B115	604.13.612

AVOID ACCIDENTS

The majority of accidents and injuries which occur in industry, on the farm, at home or on the road, are caused by the failure of some individual to follow simple and fundamental safety rules or precautions. For this reason **MOST ACCIDENTS CAN BE PREVENTED** by recognizing the real cause and taking the necessary precautions, before the accident occurs.

Regardless of the care used in design and construction of any type of equipment, there may be conditions that cannot be completely safeguarded against, without interfering with reasonable accessibility and efficient operation.

A careful operator and / or technician is the best insurance against accidents. The complete observance of one simple rule would prevent many thousands of serious injuries each year.

This rule is: Never attempt to clean, lubricate or adjust a machine while it is in motion.

WARNING

Before carrying out any maintenance operation, adjustment and or repair on machines equipped with attachments, controlled hydraulically or mechanically, make sure that the attachment is lowered and safely set on the ground. If it is necessary to have the equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the hydraulic lift cylinders, cable and /or mechanical device used for controlling the equipment.

CNH AMERICA LLC
245 E North Avenue
Carol Stream, IL 60188 U.S.A.

All rights reserved. Reproduction of text or illustrations, in whole or in part, is strictly prohibited.

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$