



EXCAVATOR

E130

**SERVICE
MANUAL**

87360591 NA

Issued 01-2006





SHOP MANUAL

E130

CRAWLER EXCAVATOR

CNH America, LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

| Revision History | | | |
|------------------|------------|--------------------|-------------|
| Issue | Issue Date | Applicable Machine | Remarks |
| First Edition | 01-2006 | E130 | 87360591 NA |

SHOP MANUAL

E130

CRAWLER EXCAVATOR

TABLE OF CONTENTS

SECTION 1

STANDARD SPECIFICATIONS AND MAINTENANCE

Table of Contents I
 (Book/Form Number: 5-1280 NA)

CHAPTER 1

GENERAL INFORMATION AND SAFETY

Table of Contents 1-1
 (Book/Form Number: 5-1290 NA)

CHAPTER 2

SPECIFICATIONS

Table of Contents 2-1
 (Book/Form Number: 5-1300 NA)

CHAPTER 3

ATTACHMENT DIMENSIONS

Table of Contents 3-1
 (Book/Form Number: 5-1310 NA)

CHAPTER 11

TOOLS

Table of Contents 11-1
 (Book/Form Number: 5-1320 NA)

CHAPTER 12

STANDARD MAINTENANCE TIME TABLE

Table of Contents 12-1
 (Book/Form Number: 5-1330 NA)

CHAPTER 13

MAINTENANCE STANDARDS AND TEST PROCEDURES

Table of Contents 13-1
 (Book/Form Number: 5-1340 NA)

SECTION 2

HYDRAULIC, ELECTRICAL, AND COMPONENT SYSTEMS

Table of Contents I
 (Book/Form Number: 5-1350 NA)

CHAPTER 21

MECHATRO CONTROL SYSTEM

Table of Contents 21-1
 (Book/Form Number: 5-1520 NA)

CHAPTER 22

HYDRAULIC SYSTEM

Table of Contents 22-1
 (Book/Form Number: 5-1360 NA)

CHAPTER 23

ELECTRICAL SYSTEM

Table of Contents 23-1
 (Book/Form Number: 5-1370 NA)

CHAPTER 24

COMPONENTS SYSTEM

Table of Contents 24-1
 (Book/Form Number: 5-1380 NA)

| | | |
|---|-------------------------------|------|
| CHAPTER 25 | | |
| AIR CONDITIONING SYSTEM | | |
| Table of Contents | | 25-1 |
| | (Book/Form Number: 5-1390 NA) | |
| SECTION 3 | | |
| GENERAL DISASSEMBLY AND ASSEMBLY | | |
| Table of Contents | | I |
| | (Book/Form Number: 5-1400 NA) | |
| CHAPTER 31 | | |
| GENERAL DISASSEMBLY AND ASSEMBLY | | |
| Table of Contents | | 31-1 |
| | (Book/Form Number: 5-1410 NA) | |
| CHAPTER 32 | | |
| ATTACHMENTS | | |
| Table of Contents | | 32-1 |
| | (Book/Form Number: 5-1420 NA) | |
| CHAPTER 33 | | |
| UPPER SLEWING STRUCTURE | | |
| Table of Contents | | 33-I |
| | (Book/Form Number: 5-1430 NA) | |
| CHAPTER 34 | | |
| TRAVEL SYSTEM | | |
| Table of Contents | | 34-1 |
| | (Book/Form Number: 5-1440 NA) | |
| SECTION 4 | | |
| TROUBLESHOOTING | | |
| Table of Contents | | I |
| | (Book/Form Number: 5-1450 NA) | |
| CHAPTER 41 | | |
| MECHTRO CONTROL | | |
| Table of Contents | | 41-1 |
| | (Book/Form Number: 5-1460 NA) | |
| CHAPTER 42 | | |
| TROUBLESHOOTING (HYDRAULIC SYSTEM) | | |
| Table of Contents | | 42-1 |
| | (Book/Form Number: 5-1470 NA) | |
| CHAPTER 43 | | |
| TROUBLESHOOTING (ELECTRICAL SYSTEM) | | |
| Table of Contents | | 43-1 |
| | (Book/Form Number: 5-1480 NA) | |
| CHAPTER 44 | | |
| TROUBLESHOOTING (ENGINE) | | |
| Table of Contents | | 44-1 |
| | (Book/Form Number: 5-1490 NA) | |
| SECTION 5 | | |
| ENGINE | | |
| Table of Contents | | I |
| | (Book/Form Number: 5-1500 NA) | |
| CHAPTER 51 | | |
| | | 1 |
| | (Book/Form Number: 5-1510 NA) | |

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$