

# SHOP MANUAL EH30.B AND EH35.B HYDRAULIC EXCAVATORS TABLE OF CONTENTS

## SECTION 1

### STANDARD SPECIFICATIONS AND MAINTENANCE

Table of Contents		I
	(Book/Form Number: 6-78360 NA)	
CHAPTER 1		
GENERAL INFORMATION AND SAFETY		
Table of Contents		1-1
	(Book/Form Number: 6-78370 NA)	
CHAPTER 2		
SPECIFICATIONS		
Table of Contents		2-1
	(Book/Form Number: 6-78380 NA)	
CHAPTER 3		
ATTACHMENT DIMENSIONS		
Table of Contents		3-1
	(Book/Form Number: 6-78390 NA)	
CHAPTER 11		
TOOLS		
Table of Contents		11-1
	(Book/Form Number: 6-78400 NA)	
CHAPTER 12		
STANDARD MAINTENANCE TIME TABLE		
Table of Contents		12-1
	(Book/Form Number: 6-78410 NA)	
CHAPTER 13		
MAINTENANCE STANDARDS AND TEST PROCEDURES		
Table of Contents		13-1
	(Book/Form Number: 6-78420 NA)	

## SECTION 2

### HYDRAULIC, ELECTRICAL, AND COMPONENT SYSTEMS

Table of Contents		I
	(Book/Form Number: 6-78430 NA)	
CHAPTER 22		
HYDRAULIC SYSTEM		
Table of Contents		22-1
	(Book/Form Number: 6-78440 NA)	
CHAPTER 23		
ELECTRICAL SYSTEM		
Table of Contents		23-1
	(Book/Form Number: 6-78450 NA)	
CHAPTER 24		
COMPONENTS SYSTEM		
Table of Contents		24-1
	(Book/Form Number: 6-78460 NA)	

SECTION 3

**DISASSEMBLY AND ASSEMBLY**

Table of Contents .....I  
(Book/Form Number: 6-78470 NA)

CHAPTER 31

**GENERAL DISASSEMBLY AND ASSEMBLY**

Table of Contents..... 31-1  
(Book/Form Number: 6-78480 NA)

CHAPTER 32

**ATTACHMENTS**

Table of Contents..... 32-1  
(Book/Form Number: 6-78490 NA)

CHAPTER 33

**UPPER SLEWING STRUCTURE**

Table of Contents..... 33-1  
(Book/Form Number: 6-78500 NA)

CHAPTER 34

**TRAVEL SYSTEM**

Table of Contents..... 34-1  
(Book/Form Number: 6-78510 NA)

SECTION 4

**TROUBLESHOOTING**

Table of Contents .....I  
(Book/Form Number: 6-78520 NA)

CHAPTER 42

**TROUBLESHOOTING (HYDRAULIC SYSTEM)**

Table of Contents..... 42-1  
(Book/Form Number: 6-78530 NA)

CHAPTER 43

**TROUBLESHOOTING (ELECTRICAL SYSTEM)**

Table of Contents..... 43-1  
(Book/Form Number: 6-78540 NA)

CHAPTER 44

**TROUBLESHOOTING (ENGINE)**

Table of Contents..... 44-1  
(Book/Form Number: 6-78550 NA)

SECTION 5

**ENGINE**

Table of Contents .....I  
(Book/Form Number: 6-78570 NA)

CHAPTER 51

**THIS MANUAL EXPLAINS THE ENGINE PROPER AND IS FAITHFUL TO  
YANMAR DIESEL ENGINE'S SERVICE MANUALS.**

..... 1  
(Book/Form Number: 6-78580 NA)



**NEW HOLLAND**  
**CONSTRUCTION**

---

# **SHOP MANUAL - SECTION 1**

---

**EH30.B AND EH35.B**  
**HYDRAULIC EXCAVATORS**

**STANDARD SPECIFICATIONS**  
**AND MAINTENANCE**

---

SECTION 1 - STANDARD SPECIFICATIONS AND MAINTENANCE

---

CNH America, LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

---

Revision History			
Issue	Issue Date	Applicable Machines	Remarks
First Edition	August, 2004	EH30.B: PW11-30001~ EH35.B: PX12-11001~	S5PW0006E01 (Section 1 title page)

# SECTION 1 STANDARD SPECIFICATIONS AND MAINTENANCE

## TABLE OF CONTENTS

### CHAPTER 1

#### GENERAL INFORMATION AND SAFETY

TABLE OF CONTENTS . . . . .	1-1
1.1 General Safety Information . . . . .	1-3
1.2 Safety Precautions . . . . .	1-4
1.3 General Precautions for Repairs . . . . .	1-6
1.4 International Unit Conversion System . . . . .	1-9

### CHAPTER 2

#### SPECIFICATIONS

TABLE OF CONTENTS . . . . .	2-1
2.1 Components Name . . . . .	2-3
2.2 Machine Dimensions . . . . .	2-4
2.3 Specifications and Performance . . . . .	2-7
2.4 Machine and Components Weights (Dry) . . . . .	2-8
2.5 Transportation . . . . .	2-10
2.6 Type of Track Shoes . . . . .	2-12
2.7 Type of Bucket . . . . .	2-12
2.8 Engine Specifications . . . . .	2-13

### CHAPTER 3

#### ATTACHMENT DIMENSIONS

TABLE OF CONTENTS . . . . .	3-1
3.1 Boom . . . . .	3-3
3.2 Arm . . . . .	3-8
3.3 Bucket . . . . .	3-15
3.4 Dozer . . . . .	3-17
3.5 Swing . . . . .	3-21

### CHAPTER 11

#### TOOLS

TABLE OF CONTENTS . . . . .	11-1
11.1 Torque Specifications for Capscrews and Nuts . . . . .	11-3
11.2 Screw and Tool Sizes . . . . .	11-5
11.3 Torque Specifications for Joints and Hoses . . . . .	11-6
11.4 Torque Specifications for Sleeve Type Tube Fittings . . . . .	11-7
11.5 Plugs . . . . .	11-8
11.6 Special Spanners for Tubes . . . . .	11-10
11.7 Special Tools . . . . .	11-11
11.8 Application of Screw Locking and Sealing Compounds . . . . .	11-11
11.9 Counterweight Lifting Jig . . . . .	11-12
11.10 Upper Frame Lifting Jig . . . . .	11-13

### CHAPTER 12

#### STANDARD MAINTENANCE TIME TABLE

TABLE OF CONTENTS . . . . .	12-1
12.1 Working Standards for Time Tables . . . . .	12-3
12.2 Time Tables . . . . .	12-4

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$