

Please cut where indicated and insert the label into the plastic pocket on the spine of the binder.



**SKID-STEER
LOADER
REPAIR**

L465, Lx465, Lx485

**Vol. 1
86587274**




**SKID-STEER
LOADER
REPAIR**

L465, Lx465, Lx485

**Vol. 1
86587274**





NEW HOLLAND


L465

Lx465

Lx485

**Section 1 -
General Information**

**REPAIR
MANUAL**



L465, Lx465, Lx485 SKID-STEER LOADER REPAIR MANUAL CONTENTS



SECTION 1 - GENERAL INFORMATION

SECTION 2 - ENGINE

SECTION 3 - ELECTRICAL SYSTEM

SECTION 4 - FINAL DRIVE, AXLES, BRAKES

SECTION 5 - HYDROSTATIC SYSTEM AND STEERING SYSTEM

SECTION 6 - HYDRAULIC SYSTEM

**SECTION 7 - SEAT, CAB, ROPS, BOOM LOCK, BOOM,
ATTACHMENT MOUNTING PLATE**

SECTION 8 - OPTIONAL EQUIPMENT

SECTION 1

GENERAL INFORMATION

CONTENTS

INTRODUCTION	1-2
ABOUT IMPROVEMENTS	1-2
SAFETY INFORMATION	
Precautionary Statements	1-3
Safety Precaution Information	1-4
Safety Decals	1-8
General Safety Information	1-11
MACHINE MODEL AND SERIAL NUMBER LOCATION	1-13
ENGINE MODEL AND SERIAL NUMBER LOCATION	1-13
HARDWARE TORQUE SPECIFICATIONS CHART	1-14
HYDRAULIC TUBE AND FITTING INSTALLATION	1-16
HYDRAULIC TUBE AND FITTING TORQUE SPECIFICATIONS ...	1-16
PROPERLY SUPPORT A RAISED MACHINE	1-17
PROPERLY SUPPORT BOOM ON BOOM LOCK PINS	1-17
MAJOR UNIT OVERHAUL	1-17
CAB AND BOOM TILT PROCEDURE	1-18
CRANING THE SKID-STEER LOADER	1-25
DRILLING HOLES IN OVERHEAD DASH	1-27
ADAPTING ATTACHMENTS REQUIRING 12V ELECTRICAL	
POWER	1-28
HYDRAULIC SYSTEM COMPATIBILITY	1-30
ACCESSORY RELAY AND ENGINE FUSE BLOCK	1-31
SPECIFICATIONS	1-32
INDEX	1-37

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$