

# SERVICE MANUAL

**T4.85 / T4.95 / T4.105**  
Tractor

Part number 47531609

English  
April 2013



## SERVICE MANUAL



**T4.105, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]  
, T4.105, less cab, with mechanical or power shuttle transmission  
[ZxJY5xxxx] , T4.105, with cab, with hi-lo transmission [ZxJY5xxxx] , T4.105,  
with cab, with mechanical or power shuttle transmission [ZxJY5xxxx] ,  
T4.105, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]  
, T4.85, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]  
, T4.85, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]**



**, T4.85, with cab, with hi-lo transmission [ZxJY5xxxx] , T4.85, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx] , T4.85, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx] , T4.95, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx] , T4.95, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx] , T4.95, with cab, with hi-lo transmission [ZxJY5xxxx] , T4.95, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx] , T4.95, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]**

## Link Product / Engine

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
T4.105, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	North America	F5DFL413L*A001
T4.105, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	Europe	F5DFL413L*A001
T4.105, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	International Region	F5DFL413L*A001
T4.105, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	Europe	F5DFL413L*A001
T4.105, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	International Region	F5DFL413L*A001
T4.105, with cab, with hi-lo transmission [ZxJY5xxxx]	Europe	F5DFL413L*A001
T4.105, with cab, with hi-lo transmission [ZxJY5xxxx]	International Region	F5DFL413L*A001
T4.85, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	North America	F5DFL413J*A001
T4.85, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	North America	F5DFL413J*A001
T4.85, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	International Region	F5DFL413J*A001

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
T4.85, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	Europe	F5DFL413J*A001
T4.85, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	Europe	F5DFL413J*A001
T4.85, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	International Region	F5DFL413J*A001
T4.85, with cab, with hi-lo transmission [ZxJY5xxxx]	Europe	F5DFL413J*A001
T4.85, with cab, with hi-lo transmission [ZxJY5xxxx]	International Region	F5DFL413J*A001
T4.95, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	North America	F5DFL413K*A001
T4.95, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	North America	F5DFL413K*A001
T4.95, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	International Region	F5DFL413K*A001
T4.95, less cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	Europe	F5DFL413K*A001
T4.95, with cab, with mechanical or power shuttle transmission [ZxJY5xxxx]	International Region	F5DFL413K*A001

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$