



REPAIR MANUAL



- T8010
- T8020
- T8030
- T8040
- T8050



REPAIR MANUAL



- T8010
- T8020
- T8030
- T8040
- T8050

Contents

INTRODUCTION

DISTRIBUTION SYSTEMS

PRIMARY HYDRAULIC POWER SYSTEM	A.10.A
PRIMARY HYDRAULIC POWER SYSTEM Electro-hydraulic remote valve	A.10.C
ELECTRICAL POWER SYSTEM	A.30.A
LIGHTING SYSTEM	A.40.A
ELECTRONIC SYSTEM	A.50.A
FAULT CODES	A.50.A

POWER PRODUCTION

ENGINE	B.10.A
FUEL AND INJECTION SYSTEM	B.20.A
ENGINE COOLANT SYSTEM	B.50.A
LUBRICATION SYSTEM	B.60.A
STARTING SYSTEM	B.80.A

POWER TRAIN

TRANSMISSION Powershift	C.20.E
REAR PTO Hydraulic	C.40.C
BAR AXLE	C.60.A

TRAVELLING

FRONT AXLE	D.10.A
2WD-4WD SYSTEM Hydraulic	D.14.C
STEERING Hydraulic	D.20.C
SERVICE BRAKE Hydraulic	D.30.C
PARKING BRAKE Hydraulic	D.32.C
WHEELS AND TRACKS Wheels	D.50.C

BODY AND STRUCTURE

SHIELD	E.20.A
USER CONTROLS AND SEAT	E.32.A

Contents

INTRODUCTION

DISTRIBUTION SYSTEMS

PRIMARY HYDRAULIC POWER SYSTEM	A.10.A
PRIMARY HYDRAULIC POWER SYSTEM Electro-hydraulic remote valve	A.10.C
ELECTRICAL POWER SYSTEM	A.30.A
LIGHTING SYSTEM	A.40.A
ELECTRONIC SYSTEM	A.50.A
FAULT CODES	A.50.A

POWER PRODUCTION

ENGINE	B.10.A
FUEL AND INJECTION SYSTEM	B.20.A
ENGINE COOLANT SYSTEM	B.50.A
LUBRICATION SYSTEM	B.60.A
STARTING SYSTEM	B.80.A

POWER TRAIN

TRANSMISSION Powershift	C.20.E
REAR PTO Hydraulic	C.40.C
BAR AXLE	C.60.A

TRAVELLING

FRONT AXLE	D.10.A
2WD-4WD SYSTEM Hydraulic	D.14.C
STEERING Hydraulic	D.20.C
SERVICE BRAKE Hydraulic	D.30.C
PARKING BRAKE Hydraulic	D.32.C
WHEELS AND TRACKS Wheels	D.50.C

BODY AND STRUCTURE

SHIELD	E.20.A
USER CONTROLS AND SEAT	E.32.A

USER CONTROLS AND SEAT Operator seat

E.32.C

USER PLATFORM

E.34.A

ENVIRONMENT CONTROL Heating, ventilation and air-conditioning

E.40.D

SAFETY SECURITY ACCESSORIES Safety

E.50.B

WORKING ARM

H

HITCH Rear hitch

H.10.C

USER CONTROLS AND SEAT Operator seat

E.32.C

USER PLATFORM

E.34.A

ENVIRONMENT CONTROL Heating, ventilation and air-conditioning

E.40.D

SAFETY SECURITY ACCESSORIES Safety

E.50.B

WORKING ARM

H

HITCH Rear hitch

H.10.C



INTRODUCTION



INTRODUCTION

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$