

EXCAVATOR

MH2.6 MH3.6

SERVICE MANUAL



F24062

IMPORTANT:

Data contained in this manual was current at the time of publication. As the Manufacturer improves constantly his products, some information may result as not updated. If variances are observed, contact your Dealer and After-Sales Service.

NEW HOLLAND KOBELCO CONSTRUCTION MACHINERY S.p.A. - ENGINEERING**PRINT 604.13.477****January 2005 issue - Printed in Italy**

TO READER

- **This manual has been printed for a skilful engineer to supply necessary technical information to carry out service operations on this machine.**
 - **Read carefully this manual to collect correct information relevant to repair procedures.**
 - **For any question or remark, or in case of any error relevant the contents of this manual, please contact :**

NEWHOLLAND KOBELCO CONSTRUCTION
MACHINERY S.p.A.
Strada di Settimo, 323
San Mauro Torinese (TO)
10099 ITALIA
PRODUCT SUPPORT
Fax. ++39 011 0077357

FURTHER REFERENCE

- Beyond this service manual, also refer to documents hereunder listed:
 - **Operator's manual**
 - **Parts Catalogue**

COMPOSITION OF COMPLETE HANDBOOK FOR INSTRUCTIONS AND REPAIRS

- The complete service manual consists of two volumes:

MH2.6 - MH3.6
Service Manual Excavator

MH2.6 - MH3.6
Service Manual Engine

- The Service Manuals for Excavator and Engine contain the necessary technical information to carry out service and repair on machine and on engine, necessary tools to carry out those operations and information on service standard, on procedures for connection, disconnection, disassembly and assembly of parts.
- The complete Service Manual relevant to the excavator models **MH2.6, MH3.6** consists of following volumes, which can be identified through relevant print out no. as stated hereunder:

VOLUME	MACHINE TYPE	PRINT NUMBER
- Service Manual - Excavator	MH2.6 - MH3.6	604.13.477
- Service Manual - Engine	MH2.6 - MH3.6	604.13.582

AVOID ACCIDENTS

The majority of accidents and injuries which occur in plants, in farms and at home or on roads, are caused by the non-observance of some simple and fundamental rules of precaution and safety. For this reason in the MAJORITY OF CASES THEY CAN BE AVOIDED: it is sufficient to foresee possible causes and to act according with the necessary precaution and care.

With any type of machine, as much as good planned or built, it is impossible to absolutely avoid risks of accidents without involving negatively some essential features for a reasonable access and an efficient operation.

Read carefully the indication and cautions of this manual contained in the SECTION SAFETY PRECAUTIONS .

A careful and cautious operator is the best warranty against accidents.

The careful observation of a single and elementary safety precautions would be enough to avoid many serious accidents. This precaution is:

Never attempt any cleaning, lubrication or maintenance operation when machine is moving.



WARNING

Before carrying out any maintenance operation, adjustment and or repair on machines equipped with attachments, controlled hydraulically or mechanically, make sure that the attachment is lowered and safely set on the ground. If in order to get access to a machine part it is necessary to hold the attachment lifted, this should duly be supported by means that are not use to control the machine.

**COPYRIGHT BY NEW HOLLAND KOBELCO CONSTRUCTION MACHIN-
ERY S.p.A.**


Product Support - Documentation Centre

Strada di Settimo, 323 - S. Mauro T.SE (TO) ITALY

All rights reserved. Reproduction of text or illustrations, in whole or in part, is strictly prohibited

MH2.6

MH3.6



SECTION 1

MAIN OPERATING RULES

INDEX

Sections index	1-1
Introduction	1-3
Foreword	1-3
Manual handling	1-3
Symbols and indications	1-4
Features of the manual	1-5
Manual composition	1-5
Brief information for manual consultation	1-7

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$