

Shop Manual

MOTOR GRADER

GD705-5

SERIAL NUMBERS 26001 and up

ecot3

KOMATSU

SHOP MANUAL

MOTOR GRADER GD705-5

Machine model	Serial number
GD705-5	26001 and up

00 Index and foreword

Table of contents

Composition of shop manual

Notice of revision.....	1
00 Index and foreword	
Table of contents	00 - 2
Foreword and general information	00 - 5
Safety notice	00 - 5
How to read the shop manual	00 - 10
Explanation of terms for maintenance standard	00 - 12
Handling of electric equipment and hydraulic components.....	00 - 14
Handling of connectors newly used for engines	00 - 23
How to read electric wire code	00 - 26
Precautions when carrying out work.....	00 - 29
Method of disassembling and connecting push-pull type coupler.....	00 - 32
Standard tightening torque table.....	00 - 35
List of Abbreviation	00 - 39
Conversion table	00 - 43
01 Specification	
Specification drawing	01 - 3
Specifications.....	01 - 5
Weight table	01 - 11
Table of fuel, coolant and lubricants	01 - 12
10 Structure and function	
Engine and cooling system	10 - 4
Cooling system	10 - 4
Cooling fan motor.....	10 - 6
Power train system	10 - 13
Power train system drawing.....	10 - 13
Power train piping drawing.....	10 - 14
Transmission control.....	10 - 15
Torque converter.....	10 - 16
Transmission.....	10 - 20
Transmission control valve	10 - 40
ECMV.....	10 - 42
Main relief and torque converter relief valve	10 - 49
Front axle.....	10 - 51
Final drive	10 - 54
Differential.....	10 - 57
Differential lock solenoid valve.....	10 - 59
Tandem drive	10 - 60
Steering system	10 - 63
Steering piping diagram	10 - 63
Priority valve	10 - 64
Steering valve	10 - 70
Brake system	10 - 78
Brake hydraulic piping diagram.....	10 - 78
Brake valve	10 - 79
Slack adjuster	10 - 84
Accumulator (for brake)	10 - 86

Charge valve.....	10 - 87
Wheel brake.....	10 - 92
Parking brake and bank control valve.....	10 - 93
Parking brake.....	10 - 94
Undercarriage and frame.....	10 - 95
Frame.....	10 - 95
Tire.....	10 - 96
Hydraulic system.....	10 - 97
Hydraulic system.....	10 - 97
Work equipment hydraulic component layout.....	10 -100
Work equipment control.....	10 -103
Hydraulic tank.....	10 -105
Main pump.....	10 -106
Power train pump.....	10 -118
Control valve.....	10 -120
CLSS.....	10 -129
Functions and operation by valve.....	10 -132
Swivel joint.....	10 -142
Pilot check valve.....	10 -143
Separately installed safety valve.....	10 -147
Accumulator (for blade).....	10 -148
Work equipment.....	10 -150
Circle and drawbar.....	10 -150
Blade.....	10 -152
Lifter.....	10 -154
Circle rotation motor.....	10 -156
Circle rotation gear.....	10 -158
Cab.....	10 -160
Cab.....	10 -160
Electrical system.....	10 -162
Machine monitor.....	10 -162
Automatic shift control system.....	10 -165
Transmission controller.....	10 -173
Engine controller.....	10 -176
KOMTRAX system.....	10 -179
Starting engine circuit.....	10 -184
Stopping engine circuit.....	10 -186
Preheating circuit.....	10 -187
Engine power mode select circuit.....	10 -188
Cooling fan control function.....	10 -189
Sensor.....	10 -193
20 Standard value table	
Standard value table.....	20 - 3
Standard value table for engine.....	20 - 3
Standard value table for machine.....	20 - 5
30 Testing and adjusting	
Precautions before work.....	30 -3-1
Related information on testing and adjusting.....	30 - 4
Tools for testing and adjusting.....	30 - 4
Sketch of tools for testing and adjusting.....	30 - 7
Engine and cooling system.....	30 - 8
Testing engine speed.....	30 - 8

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$