



NEW HOLLAND

CRAWLER EXCAVATOR

E175B TIER 3

REPAIR MANUAL

87634783 NA

Issued 01Feb 08



NEW HOLLAND

CONSTRUCTION

www.newhollandconstruction.com



REPAIR MANUAL

E175B

CRAWLER EXCAVATOR

TIER 3

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History			
Issue	Issue Date	Applicable Machine	Remarks
First Edition	02-2008	E175B	CRAWLER EXCAVATOR

E175B REPAIR MANUAL

TABLE OF CONTENTS

SECTION 1

SAFETY AND GENERAL INFORMATION

Section Table of Contents	I
	Book/Form Number: 5-10610 NA
CHAPTER 1	
SAFETY PRECAUTIONS	
Table of Contents	1-1
	Book/Form Number: 5-10620 NA
CHAPTER 2	
SPECIFICATIONS	
Table of Contents	2-1
	Book/Form Number: 5-10630 NA
CHAPTER 3	
STANDARD PRECAUTIONS AND TIGHTENING TORQUES	
Table of Contents	3-1
	Book/Form Number: 5-10640 NA
CHAPTER 4	
MAINTENANCE STANDARDS AND TEST PROCEDURES	
Table of Contents	4-1
	Book/Form Number: 5-10650 NA
CHAPTER 5	
ATTACHMENT DIMENSIONS	
Table of Contents	5-1
	Book/Form Number: 5-6860 NA

SECTION 2

SYSTEMS

Section Table of Contents	I
	Book/Form Number: 5-10660 NA
CHAPTER 1	
MECHATRO CONTROL SYSTEM	
Table of Contents	1-1
	Book/Form Number: 5-10670 NA
CHAPTER 2	
HYDRAULIC SYSTEM	
Table of Contents	2-1
	Book/Form Number: 5-10680 NA
CHAPTER 3	
ELECTRICAL SYSTEM	
Table of Contents	3-1
	Book/Form Number: 5-10690 NA
CHAPTER 4	
COMPONENTS SYSTEM	
Table of Contents	4-1
	Book/Form Number: 5-10700 NA
CHAPTER 5	
AIR CONDITIONING SYSTEM	
Table of Contents	5-1
	Book/Form Number: 5-10710 NA

SECTION 3

DISASSEMBLY AND ASSEMBLY

Section Table of Contents	I
	Book/Form Number: 5-10720 NA
CHAPTER 1	
ATTACHMENTS	
Table of Contents	1-1
	Book/Form Number: 5-10730 NA
CHAPTER 2	
UPPER STRUCTURE	
Table of Contents	2-1
	Book/Form Number: 5-10740 NA

CHAPTER 3

UNDERCARRIAGE (TRAVEL SYSTEM)

Table of Contents 3-1
Book/Form Number: 5-10750 NA

SECTION 4

TROUBLESHOOTING

Section Table of ContentsI
Book/Form Number: 5-10760 NA

CHAPTER 1

TROUBLESHOOTING BY ERROR CODES

Table of Contents 1-1
Book/Form Number: 5-10770 NA

CHAPTER 2

TROUBLESHOOTING BY TROUBLE

Table of Contents 2-1
Book/Form Number: 5-10780 NA

CHAPTER 3

TROUBLESHOOTING BY DIAGNOSIS MODE

Table of Contents 3-1
Book/Form Number: 5-10790 NA

SECTION 5

ENGINE

Section Table of ContentsI
Book/Form Number: 5-10800 NA

CHAPTER 1

ENGINE

Table of Contents 1-1
Book/Form Number: 5-10810 NA

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$