

SERVICE MANUAL

T8010 / T8020 / T8030 / T8040 / T8050
Tractors

I/4

Print No. 84318454



SERVICE MANUAL



T8010 [Z8Rx06001 -]
T8020 [Z8Rx06001 -]
T8030 [Z8Rx06001 -]
T8040 [Z8Rx06001 -]
T8050 [Z8Rx06001 -]

Contents

INTRODUCTION

DISTRIBUTION SYSTEMS.....	A
PRIMARY HYDRAULIC POWER SYSTEM.....	A.10.A
PRIMARY HYDRAULIC POWER SYSTEM Electro-hydraulic remote valve.....	A.10.C
PNEUMATIC SYSTEM.....	A.20.A
ELECTRICAL POWER SYSTEM.....	A.30.A
LIGHTING SYSTEM.....	A.40.A
ELECTRONIC SYSTEM.....	A.50.A
FAULT CODES.....	A.50.A
POWER PRODUCTION.....	B
ENGINE.....	B.10.A
FUEL AND INJECTION SYSTEM.....	B.20.A
ENGINE COOLANT SYSTEM.....	B.50.A
LUBRICATION SYSTEM.....	B.60.A
STARTING SYSTEM.....	B.80.A
POWER TRAIN.....	C
TRANSMISSION Powershift.....	C.20.E
REAR PTO Hydraulic.....	C.40.C
BAR AXLE.....	C.60.A
TRAVELLING.....	D
FRONT AXLE.....	D.10.A
2WD-4WD SYSTEM Hydraulic.....	D.14.C
STEERING Hydraulic.....	D.20.C
SERVICE BRAKE Hydraulic.....	D.30.C
PARKING BRAKE Hydraulic.....	D.32.C
BRAKE CONNECTION Hydraulic.....	D.34.C
BRAKE CONNECTION Pneumatic.....	D.34.E
SUSPENSION Hydraulic.....	D.40.C

WHEELS AND TRACKS Wheels.....	D.50.C
BODY AND STRUCTURE	E
SHIELD	E.20.A
USER CONTROLS AND SEAT	E.32.A
USER CONTROLS AND SEAT Operator seat	E.32.C
USER PLATFORM	E.34.A
ENVIRONMENT CONTROL Heating, ventilation and air-conditioning.....	E.40.D
SAFETY SECURITY ACCESSORIES Safety	E.50.B
WORKING ARM	H
HITCH Rear hitch.....	H.10.C

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$