

# SERVICE MANUAL

**TK4020F / TK4020V / TK4030**  
**TK4030F / TK4030V / TK4040**  
**TK4040M / TK4050 / TK4050M / TK4060**  
Tractor

Part number 47830952  
English  
February 2015





## **SERVICE MANUAL**

**TK4020F , TK4020V , TK4030F , TK4030V , TK4030 , TK4040M , TK4040 ,  
TK4050M , TK4050 , TK4060**

# Link Product / Engine

Product	Market Product	Engine
TK4020F	Middle East Africa	F5AE9484A
TK4020F	Asia Pacific	F5AE9484A
TK4020F	Europe	F5AE9484A
TK4020F	Australia New Zealand	F5AE9484A
TK4020V	Asia Pacific	F5AE9484A
TK4020V	Australia New Zealand	F5AE9484A
TK4020V	Europe	F5AE9484A
TK4020V	Middle East Africa	F5AE9484A
TK4030	Australia New Zealand	F5AE9484B
TK4030	Middle East Africa	F5AE9484B
TK4030	Asia Pacific	F5AE9484B
TK4030	Europe	F5AE9484B
TK4030F	Middle East Africa	F5AE9484B
TK4030F	Asia Pacific	F5AE9484B
TK4030F	Europe	F5AE9484B
TK4030F	Australia New Zealand	F5AE9484B
TK4030V	Asia Pacific	F5AE9484B
TK4030V	Middle East Africa	F5AE9484B
TK4030V	Europe	F5AE9484B
TK4030V	Australia New Zealand	F5AE9484B
TK4040	Middle East Africa	F5AE9484G
TK4040	Australia New Zealand	F5AE9484G
TK4040	Europe	F5AE9484G
TK4040	Asia Pacific	F5AE9484G
TK4040M	Europe	F5AE9484G
TK4040M	Asia Pacific	F5AE9484G
TK4040M	Australia New Zealand	F5AE9484G
TK4040M	Middle East Africa	F5AE9484G
TK4050	Europe	F4CE9487N
TK4050	Australia New Zealand	F4CE9487N
TK4050	Middle East Africa	F4CE9487N
TK4050	Asia Pacific	F4CE9487N
TK4050M	Asia Pacific	F4CE9487N
TK4050M	Middle East Africa	F4CE9487N
TK4050M	Europe	F4CE9487N
TK4050M	Australia New Zealand	F4CE9487N
TK4060	Europe	F4CE9487A
TK4060	Asia Pacific	F4CE9487A
TK4060	Middle East Africa	F4CE9487A
TK4060	Australia New Zealand	F4CE9487A

# Contents

---

## INTRODUCTION

<b>Engine</b> .....	<b>10</b>
[10.001] Engine and crankcase .....	10.1
[10.216] Fuel tanks .....	10.2
[10.400] Engine cooling system .....	10.3
<b>Clutch</b> .....	<b>18</b>
[18.104] Clutch hydraulic release control.....	18.1
[18.100] Clutch mechanical release control .....	18.2
[18.110] Clutch and components .....	18.3
<b>Transmission</b> .....	<b>21</b>
[21.114] Mechanical transmission .....	21.1
[21.118] Transmission/Rear drive .....	21.2
[21.140] Mechanical transmission internal components.....	21.3
[21.148] Transmission/Rear drive internal components .....	21.4
[21.160] Creeper .....	21.5
[21.162] Reverser .....	21.6
<b>Rear axle system</b> .....	<b>27</b>
[27.100] Powered rear axle.....	27.1
[27.126] Spur gear and final drives.....	27.2
<b>Power Take-Off (PTO)</b> .....	<b>31</b>
[31.114] Two-speed rear Power Take-Off (PTO) .....	31.1
<b>Brakes and controls</b> .....	<b>33</b>
[33.120] Mechanical service brakes.....	33.1
[33.202] Hydraulic service brakes .....	33.2
<b>Hydraulic systems</b> .....	<b>35</b>
[35.114] Three-point hitch control valve .....	35.1

[35.322] Regulated/Low pressure system .....	35.2
[35.204] Remote control valves .....	35.3
<b>Steering clutches .....</b>	<b>46</b>
[46.110] Steering clutch .....	46.1
<b>Tracks and track suspension .....</b>	<b>48</b>
[48.130] Track frame and driving wheels .....	48.1
[48.100] Tracks .....	48.2
[48.110] Front suspension .....	48.3
[48.114] Rear suspension .....	48.4
[48.134] Track tension units .....	48.5
[48.138] Track rollers .....	48.6
<b>Electrical systems .....</b>	<b>55</b>
[55.100] Harnesses and connectors .....	55.1
[55.201] Engine starting system .....	55.2
[55.301] Alternator .....	55.3
[55.302] Battery .....	55.4
[55.640] Electronic modules .....	55.5
[55.404] External lighting .....	55.6
[55.408] Warning indicators, alarms, and instruments .....	55.7
[55.DTC] FAULT CODES .....	55.8
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.150] Cab .....	90.1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$