

# Shop Manual

MOTOR GRADER

**GD755-5R**

SERIAL NUMBERS 10001 and up

**KOMATSU**



# MOTOR GRADER GD755-5R

Machine model	Serial number
GD755-5R	10001 and up

---

## 00 Index and Foreword

### 100 Index

---

---

Composition of shop manual .....	2
Table of contents .....	4

## Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Section Title .....	Form Number
Shop Manual, contents binder, binder label and tabs .....	SEN05668-08
00 Index and foreword .....	SEN05669-08
100 Index .....	SEN05677-08
200 Foreword and general information .....	SEN05678-02
01 Specification .....	SEN05670-00
100 Specification and technical data .....	SEN05679-00
10 Structure,function and maintenance standard .....	SEN05671-01
100 Engine and cooling system .....	SEN05680-00
200 Power train.....	SEN05681-00
300 Steering system .....	SEN05682-00
400 Brake system .....	SEN05683-00
500 Undercarriage and frame .....	SEN05684-00
601 Hydraulic system, Part 1 .....	SEN05685-01
602 Hydraulic system, Part 2.....	SEN05686-00
700 Work equipment.....	SEN05687-00
800 Cab and its attachments .....	SEN05688-00
900 Electrical system .....	SEN05689-00
20 Standard value table.....	SEN05672-02
100 Specification and technical data .....	SEN05696-02
30 Testing and adjusting.....	SEN05673-05
101 Testing and adjusting, Part 1 .....	SEN05697-01
102 Testing and adjusting, Part 2 .....	SEN05698-02
103 Testing and adjusting, Part 3.....	SEN05699-03
40 Troubleshooting .....	SEN05674-02
100 Failure code table and fuse locations .....	SEN05700-01
200 General Information on troubleshooting .....	SEN05701-00
301 Troubleshooting by failure code, Part 1 .....	SEN05702-00
302 Troubleshooting by failure code, Part 2 .....	SEN05703-00
303 Troubleshooting by failure code, Part 3 .....	SEN05704-00
304 Troubleshooting by failure code, Part 4 .....	SEN05705-01
305 Troubleshooting by failure code, Part 5 .....	SEN05706-00
400 Troubleshooting of electrical system (E-mode) .....	SEN05707-00
500 Troubleshooting of hydraulic and mechanical system (H-mode) .....	SEN05708-00
600 Troubleshooting of engine (S-mode) .....	SEN05709-00
50 Disassembly and assembly .....	SEN05675-06
100 General information on disassembly and assembly .....	SEN05790-02
200 Engine and cooling system .....	SEN05791-00
300 Power train.....	SEN05792-05

400 Brake system .....	SEN05793-01
500 Undercarriage and frame .....	SEN05794-00
600 Hydraulic system .....	SEN05795-00
700 Work equipment .....	SEN05796-00
800 Cab and its attachments .....	SEN05797-00
900 Electric system.....	SEN05798-00
80 Air conditioner.....	SEN05714-01
100 Air conditioner.....	SEN05715-01
90 Diagrams and drawings .....	SEN05676-00
100 Hydraulic diagrams and drawings.....	SEN05690-00
200 Electrical diagrams and drawings .....	SEN05691-00

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$