

Shop Manual

PC308USLC-3E0

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC308USLC-3E0 30001 and up

ENGINE SAA6D107E-1

This material is proprietary to Komatsu America Corp. and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Copyright 2011 Komatsu
Printed in U.S.A.
Komatsu America Corp.

August 2011

HYDRAULIC EXCAVATOR

PC308USLC-3E0

Machine model	Serial number
PC308USLC-3E0	30001 and up

00 Index and foreword

Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN00964-08
00 Index and foreword	SEN00965-08
Index	SEN00966-08 ●
Foreword and general information	SEN00967-02
01 Specification	SEN00968-00
Specification and technical data	SEN00969-00
10 Structure, function and maintenance standard	SEN00970-05
Engine and cooling system	SEN00971-00
Power train	SEN00972-00
Undercarriage and frame	SEN00973-00
Hydraulic system, Part 1	SEN00974-00
Hydraulic system, Part 2	SEN00975-00
Hydraulic system, Part 3	SEN00976-01 ●
Work equipment	SEN00977-00
Cab and its attachments	SEN00978-00
Electrical system	SEN00979-04
20 Standard value table	SEN00980-01
Standard service value table	SEN01071-01
30 Testing and adjusting	SEN00981-02
Testing and adjusting, Part 1	SEN01072-02
Testing and adjusting, Part 2	SEN01073-02
40 Troubleshooting	SEN00982-02
Failure code table and fuse locations	SEN03365-00
General information on troubleshooting	SEN01074-02
Troubleshooting by failure code (Display of code), Part 1	SEN01075-02
Troubleshooting by failure code (Display of code), Part 2	SEN01076-02
Troubleshooting by failure code (Display of code), Part 3	SEN01077-01
Troubleshooting of electrical system (E-mode)	SEN01078-02
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01079-01
Troubleshooting of engine (S-mode)	SEN01080-02

50 Disassembly and assembly	SEN01675-02
General information on disassembly and assembly	SEN01120-02
Engine and cooling system	SEN01121-02
Power train.....	SEN01122-01
Undercarriage and frame.....	SEN01123-01
Hydraulic system	SEN01124-01
Work equipment.....	SEN01125-00
Cab and its attachments	SEN01126-01
Electrical system.....	SEN01127-01
90 Diagrams and drawings.....	SEN00983-01
Hydraulic diagrams and drawings.....	SEN00984-00
Electrical diagrams and drawings.....	SEN00985-01

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$