

SHOP MANUAL

GALEO

PC35MR-2

PC50MR-2

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC35MR-2 F00103 and up

PC50MR-2 F00103 and up

KOMATSU
Utility

SHOP MANUAL



GALEO

PC35MR-2

PC50MR-2

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC35MR-2 F00103 and up

PC50MR-2 F00103 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC35MR-2 mount the 3D88E-5P and PC50MR-2 mount the 4D88E-5X engine.
- For details of the engine, see the 68E-88E Series Engine Shop Manual.

CONTENTS

	No. of page
01 GENERAL	01-1
10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD	10-1
20 TESTING AND ADJUSTING	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
90 OTHERS	90-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	00-1			10-1			10-42			10-83			10-124	
	00-2			10-2			10-43			10-84			10-125	
	00-2-1			10-3			10-44			10-85			10-126	
	00-2-2			10-4			10-45			10-86			10-127	
	00-2-3			10-5			10-46			10-87			10-128	
	00-2-4			10-6			10-47			10-88			10-129	
	00-3			10-7			10-48			10-89			10-130	
	00-4			10-8			10-49			10-90			10-131	
	00-5			10-9			10-50			10-91			10-132	
	00-6			10-10			10-51			10-92			10-133	
	00-7			10-11			10-52			10-93			10-134	
	00-8			10-12			10-53			10-94			10-135	
	00-9			10-13			10-54			10-95			10-136	
	00-10			10-14			10-55			10-96			10-137	
	00-11			10-15			10-56			10-97			10-138	
	00-12			10-16			10-57			10-98				
	00-13			10-17			10-58			10-99			20-1	
	00-14			10-18			10-59			10-100			20-2	
	00-15			10-19			10-60			10-101			20-3	
	00-16			10-20			10-61			10-102			20-4	
	00-17			10-21			10-62			10-103			20-5	
	00-18			10-22			10-63			10-104			20-6	
	00-19			10-23			10-64			10-105			20-7	
	00-20			10-24			10-65			10-106			20-8	
	00-21			10-25			10-66			10-107			20-9	
	00-22			10-26			10-67			10-108			20-10	
				10-27			10-68			10-109			20-11	
	01-1			10-28			10-69			10-110			20-12	
	01-2			10-29			10-70			10-111			20-13	
	01-3			10-30			10-71			10-112			20-14	
	01-4			10-31			10-72			10-113			20-15	
	01-5			10-32			10-73			10-114			20-16	
	01-6			10-33			10-74			10-115			20-17	
	01-7			10-34			10-75			10-116			20-18	
	01-8			10-35			10-76			10-117			20-19	
	01-9			10-36			10-77			10-118			20-20	
	01-10			10-37			10-78			10-119			20-21	
	01-11			10-38			10-79			10-120			20-22	
	01-12			10-39			10-80			10-121			20-23	
	01-13			10-40			10-81			10-122			20-24	
				10-41			10-82			10-123			20-25	

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$