

Shop Manual

HYDRAULIC
EXCAVATOR

PC2000-8

SERIAL NUMBERS 20001 and up

KOMATSU

HYDRAULIC EXCAVATOR

PC2000-8

Machine model	Serial number
PC2000-8	20001 and up

00 Index and foreword

Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN01607-23
00 Index and foreword	SEN01608-23
Index	SEN01609-24 ●
Foreword and general information	SEN01610-04
01 Specification	SEN01611-04
Specification and technical data	SEN01612-04
10 Structure, function and maintenance standard	SEN01613-08
Engine and cooling system	SEN01614-01
Power train	SEN01615-01
Undercarriage and frame	SEN01616-02
Hydraulic system, Part 1	SEN01618-05
Hydraulic system, Part 2	SEN01619-02
Hydraulic system, Part 3	SEN01620-02
Work equipment	SEN01621-04
Cab and its attachments	SEN01622-01
Electrical system	SEN01623-03
20 Standard value table	SEN01624-03
Standard service value table	SEN02006-03
30 Testing and adjusting	SEN01625-09
Testing and adjusting, Part 1	SEN02007-04
Testing and adjusting, Part 2	SEN02008-05
Testing and adjusting, Part 3	SEN02009-05
Testing and adjusting, Part 4	SEN02010-05
40 Troubleshooting	SEN01626-05
Failure code table and fuse locations	SEN02011-02
General information on troubleshooting	SEN02012-05
Troubleshooting by failure code, Part 1	SEN02096-03
Troubleshooting by failure code, Part 2	SEN02097-02
Troubleshooting by failure code, Part 3	SEN02098-02
Troubleshooting by failure code, Part 4	SEN02099-03

Troubleshooting by failure code, Part 5	SEN02100-03
Troubleshooting by failure code, Part 6	SEN02101-02
Troubleshooting by failure code, Part 7	SEN02102-01
Troubleshooting of electrical system (E-mode)	SEN02103-02
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN02104-03
Troubleshooting of mechanical system (S-mode)	SEN02105-02
50 Disassembly and assembly	SEN01627-13
General information on disassembly and assembly	SEN02133-06
Engine and cooling system	SEN02134-04
Engine	SEN02135-07
Power train	SEN02136-02
Undercarriage and frame	SEN02137-03
Hydraulic system	SEN02138-04 ●
Work equipment	SEN02139-01
Cab and its attachments	SEN02140-03
Electrical system	SEN02141-04 ●
90 Diagrams and drawings	SEN01628-10
Hydraulic diagrams and drawings	SEN01629-02
Electrical diagrams and drawings	SEN01630-09

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$