

Shop Manual

HYDRAULIC
MINING
SHOVEL

PC4000E-6

SERIAL NUMBER 08165- up

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and must be periodically reviewed by all personnel who will come into contact with it.

Komatsu has Operation and Maintenance Manuals written in other languages. If a foreign language manual is required, contact your local distributor for availability.

KOMATSU

COPYRIGHT

This material is property of Komatsu Mining Germany GmbH and is not to be reproduced, used, or disclosed except in accordance with the written authorization of Komatsu Mining Germany GmbH. It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that the customer contact their distributor for information on the latest revision.



HYDRAULIC MINING EXCAVATOR

PC4000E-6

Machine model	Serial numbers
PC4000E-6	08165 and up

00 Foreword

© Copyright 2009 KOMATSU MINING GERMANY GmbH



It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$