Shop Manual

HYDRAULIC EXCAVATOR

PC600 -8R PC600LC-8R

SERIAL NUMBERS 60001 and up



HYDRAULIC EXCAVATOR

PC600-8R PC600LC-8R

Machine model Serial number

PC600-8R 60001 and up PC600LC-8R 60001 and up

00 Index and foreword

Index

Composition of shop manual	2
Table of contents	4

SEN02404-19 00 Index and foreword

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN02402-19
00 Index and foreword Index Foreword and general information	SEN02403-19 SEN02404-19 SEN02405-05
01 Specification Specification and technical data	SEN02406-02 SEN02407-02
10 Structure, function and maintenance standard Engine and cooling system Power train Undercarriage and frame Hydraulic system, Part 1 Hydraulic system, Part 2 Work equipment Cab and its attachments Electrical system	SEN02408-11 SEN02409-01 SEN02410-03 SEN02411-00 SEN02412-01 SEN02413-05 SEN02414-01 SEN02415-00 SEN02416-05
20 Standard value table Standard service value table	SEN02417-02 SEN02843-02
30 Testing and adjusting Testing and adjusting, Part 1 Testing and adjusting, Part 2	SEN02418-04 SEN02844-04 SEN02845-03
40 Troubleshooting Failure code table and fuse locations General information on troubleshooting Troubleshooting by failure code (Display of code), Part 1 Troubleshooting by failure code (Display of code), Part 2 Troubleshooting by failure code (Display of code), Part 3 Troubleshooting of electrical system (E-mode) Troubleshooting of hydraulic and mechanical system (H-mode) Troubleshooting of engine (S-mode)	SEN02419-05 SEN02846-04 SEN02847-03 SEN02848-02 SEN02849-03 SEN02850-02 SEN02851-03 SEN02852-02 SEN02853-02
50 Disassembly and assembly General information on disassembly and assembly Engine and cooling system, Part 1 Engine and cooling system, Part 2 Power train Undercarriage and frame Hydraulic system Work equipment Cab and its attachments Electrical system	SEN02420-08 SEN02776-05 SEN02777-02 SEN02778-01 SEN02779-03 SEN02780-04 SEN02781-03 SEN02782-02 SEN02783-02 SEN02784-01

2 PC600-8R

00 Index and foreword SEN02404-19

90 Diagrams and drawings	SEN02421-04
Hydraulic diagrams and drawings	SEN02422-02
Electrical diagrams and drawings	SEN02423-03

PC600-8R 3

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$