

Spelliatisse and y CEBMOS 2406 Mainteh Sappel Habital Supplement



DIOMPITRUSKRIPTION

SERIAL NUMBERS SERIAL NUMBERS SERIAL NUMBERS SERIAL NUMBERS



This material is proprietary to Komatsu and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.



© Copyright 2024 Komatsu Ltd. or one of its subsidiaries All Rights Reserved Printed in the U.S.A.

DUMP TRUCK

730E

| Machine model Serial numb | er |
|---------------------------|----|
|---------------------------|----|

730E-8 A40004 - A40017,

A40035 - A40040, A40045 - A40064, A40067 and up

00 Index and foreword

Index

| Composition of shop manual | 2 |
|----------------------------|-----|
| Table of contents | . 4 |

CEN00039-06 00 Index and foreword

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly. The marks shown to the right of Form No. denote the following:

□: New module (to be filed additionally) •: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tab No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

| Section Title | Form Number |
|---|---------------|
| Shop Manual, contents binder, binder label and tabs | CEBM032406 |
| 00 Index and foreword | |
| Index | CEN00039-06 ● |
| Foreword, safety and general information | CEN00002-16 ● |
| 01 Specification | |
| Specification and technical data | CEN01009-03 |
| 10 Structure and functions | |
| Steering circuit | CEN10076-00 |
| Hoist circuit | CEN10048-02 |
| Brake circuits | CEN10049-01 |
| Electrical system, 24 volt | CEN10051-02 |
| Electrical system, AC drive | CEN10053-00 |
| Cab air conditioning | CEN10008-04 ● |
| 20 Standard value table | |
| Standard value table | CEN20004-01 |
| 30 Testing and adjusting | |
| Steering, hoist and auxiliary hydraulic systems | CEN30084-01 ● |
| Brake system | CEN30056-02 |
| Accumulators and suspension | CEN30098-16 ● |
| Interface module 1 (IM1) | CEN30051-01 |
| KOMTRAX Plus | CEN30069-00 |
| Payload meter IV | CEN30070-05 ● |
| Komatsu Wireless Bridge (KWB) | CEN30074-00 |
| Cab air conditioning | CEN30029-02 ● |
| KomVision | CEN30105-03 ● |

2

00 Index and foreword CEN00039-06

| 40 Troubleshooting | |
|--|---------------|
| Fuse and circuit breaker locations | CEN40113-00 |
| AC drive system fault codes (DSC) | CEN40114-02 |
| Troubleshooting by fault code, Part 1 | CEN40108-00 |
| Troubleshooting by fault code, Part 2 | CEN40109-00 |
| Troubleshooting by fault code, Part 3 | CEN40110-00 |
| Troubleshooting by fault code, Part 4 | CEN40111-01 |
| Troubleshooting by fault code, Part 5 | CEN40112-00 |
| Cab air conditioning | CEN40008-02 |
| Steering system | CEN40185-01 |
| KomVision | CEN40200-01 |
| Automatic lubrication (auto lube) system | CEN40202-01 ● |
| 50 Disassembly and assembly | |
| Service tools | CEN50036-05 ● |
| Wheels, spindles and rear axle | CEN50037-05 ● |
| Brake system | CEN50038-01 |
| Steering system | CEN50039-00 |
| Suspensions | CEN50040-02 ● |
| Hoist circuit | CEN50116-01 ● |
| Body and structures | CEN50100-01 ● |
| Operator cab | CEN50042-00 |
| Cab air conditioning | CEN50028-03 |
| Power module | CEN50101-01 |
| 90 Diagrams and drawings | |
| Hydraulic circuit diagrams | CEN90021-00 |
| Electrical circuit diagrams | CEN90022-03 |
| | |

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$