

Statistics and y CEBWOS 2508 Blacktan SuppleMacuitle Supplement



DUMPITRUSKRIPTION

SERIAL NUMBERS SERIAL NUMBERS SERIAL NUMBERS SERIAL NUMBERS



This material is proprietary to Komatsu and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.



© Copyright 2024 Komatsu Ltd. or one of its subsidiaries All Rights Reserved Printed in the U.S.A.

DUMP TRUCK

730E

M	lachine	model	Serial	number
IVI	aciiii	HIIOGGI	Ocitai	HUHHACI

730E-8 A40018 - A40034,

A40041 - A40044, A40065 - A40066

00 Index and foreword

Index

Composition of shop manual	2
Table of contents	. 4

CEN00036-03 00 Index and foreword

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly. The marks shown to the right of Form No. denote the following:

□: New module (to be filed additionally) •: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tab No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	CEBM032503
00 Index and foreword	
Index	CEN00036-03 ●
Foreword, safety and general information	CEN00002-16 ●
01 Specification	
Specification and technical data	CEN01009-03
10 Structure and functions	
Steering circuit	CEN10076-00
Hoist circuit	CEN10048-02
Brake circuits	CEN10049-01
Electrical system, 24 volt	CEN10051-02
Electrical system, AC drive	CEN10053-00
Cab air conditioning	CEN10008-04 ●
20 Standard value table	
Standard service value table	CEN20004-01
30 Testing and adjusting	
Steering, hoist and auxiliary hydraulic systems	CEN30084-01 ●
Brake system	CEN30056-02
Accumulators and suspensions	CEN30098-16 ●
Interface module 1 (IM1)	CEN30051-01
KOMTRAX Plus	CEN30083-00
Payload meter IV	CEN30070-05 ●
Cab air conditioning	CEN30029-02 ●

00 Index and foreword CEN00036-03

40 Traublashasting	
40 Troubleshooting Fuse and circuit breaker locations	OFNI40442 00
	CEN40113-00
AC drive system fault codes (DSC)	CEN40114-02
Troubleshooting by fault code, Part 1	CEN40108-00
Troubleshooting by fault code, Part 2	CEN40109-00
Troubleshooting by fault code, Part 3	CEN40110-00
Troubleshooting by fault code, Part 4	CEN40111-01
Troubleshooting by fault code, Part 5	CEN40112-00
Cab air conditioning	CEN40008-02
Steering system	CEN40185-01
Automatic lubrication (auto lube) system	CEN40202-01 ●
50 Disassembly and assembly	
Service tools	CEN50036-05 ●
Wheels, spindles and rear axle	CEN50037-05 ●
Brake system	CEN50038-01
Steering system	CEN50039-00
Suspensions	CEN50040-02 ●
Hoist circuit	CEN50116-01 ●
Body and structures	CEN50100-01 ●
Operator cab	CEN50042-00
Cab air conditioning	CEN50028-03
Power module	CEN50101-01
90 Diagrams and drawings	
Hydraulic circuit diagrams	CEN90021-00
Electrical circuit diagrams	CEN90022-03

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$