

Shop Manual

COMPACT
HYDRAULIC
EXCAVATOR

PC18MR-3

SERIAL NUMBERS 20001 and up

KOMATSU

HYDRAULIC EXCAVATOR

PC18MR-3

Machine model	Serial number
PC18MR-3	20001 and up

00 Index and foreword

100 Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title.....	Form Number
Shop Manual, contents binder, binder label and tabs	SEN04306-06
00 Index and foreword	SEN04307-06
100 Index	SEN04308-06 ●
200 Foreword and general information	SEN04309-00
01 Specification	SEN04310-02
100 Specification and technical data.....	SEN04311-02
10 Structure, function and maintenance standard.....	SEN04312-02
100 Engine and cooling system	SEN04313-00
200 Power train.....	SEN04314-01
300 Undercarriage and frame	SEN04315-00
410 Hydraulic system, Part 1	SEN04316-00
420 Hydraulic system, Part 2	SEN04317-00
430 Hydraulic system, Part 3	SEN04318-01
500 Work equipment.....	SEN04319-00
600 Cab and its attachments	SEN04320-00
700 Electrical system.....	SEN04321-01
20 Standard value table.....	SEN04322-04
100 Standard service value table.....	SEN04495-04 ●
30 Testing and adjusting	SEN04323-00
100 Testing and adjusting	SEN04496-00
40 Troubleshooting.....	SEN04324-01
100 General information on troubleshooting.....	SEN04497-00
200 Troubleshooting of electrical system (E-mode).....	SEN04498-01
300 Troubleshooting of hydraulic and mechanical system (H-mode)	SEN04499-00
400 Troubleshooting of engine (S-mode).....	SEN04500-00
50 Disassembly and assembly.....	SEN04325-00
100 General information on disassembly and assembly	SEN04620-00
200 Engine and cooling system	SEN04621-00
300 Power train.....	SEN04622-00

400 Undercarriage and frame	SEN04623-00
500 Hydraulic system	SEN04624-00
600 Work equipment	SEN04625-00
700 Cab and its attachments	SEN04626-00
800 Electrical system	SEN04627-00
90 Diagrams and drawings	SEN04326-02
100 Hydraulic diagrams and drawings	SEN04327-00
200 Electrical diagrams and drawings	SEN04328-02

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$