

# SHOP MANUAL

---

---

# PW98MR-6

**HYDRAULIC EXCAVATOR**

**SERIAL NUMBER**

**PW98MR-6 F00003 and up**

**KOMATSU**  
*Utility*



## CONTENTS

	Page
10. STRUCTURE AND FUNCTION.....	10-1
20. TESTING AND ADJUSTING .....	20-1
30. DISASSEMBLY AND ASSEMBLY .....	30-1
90. OTHER.....	90-1

**PAGE INTENTIONALLY  
LEFT BLANK**

## REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
( )	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

Mark	Page	Time of rev.	Mark	Page	Time of rev.	Mark	Page	Time of rev.	Mark	Page	Time of rev.	Mark	Page	Time of rev.
	00-1			10-30			10-84			20-27			20-79	
	00-2			10-31			10-85			20-28			20-80	
●	00-3	(2)		10-32			10-86			20-29			20-81	
●	00-4	(2)		10-33			10-87			20-30			20-82	
	00-5			10-34			10-88			20-31			20-83	
	00-6			10-35			10-89			20-32			20-84	
	00-7			10-36			10-90			20-33			20-85	
	00-8			10-37			10-91			20-34			20-86	
	00-9			10-38			10-92			20-35			20-87	
	00-10			10-39			10-93			20-36			20-88	
	00-11			10-40			10-94			20-37			20-89	
	00-12			10-41			10-95			20-38			20-90	
	00-13	(1)		10-42			10-96			20-39				
	00-14	(1)		10-43			10-97	(1)		20-40			30-1	(1)
	00-15			10-44			10-98	(1)		20-41			30-2	(1)
	00-16			10-45			10-99			20-42			30-3	(1)
	00-17			10-46			10-100			20-43			30-4	(1)
	00-18			10-47			10-101			20-44			30-5	(1)
	00-19			10-48			10-102			20-45			30-6	(1)
	00-20			10-49			10-103			20-46			30-7	(1)
	00-21			10-50			10-104			20-47			30-8	(1)
	00-22			10-51			10-105			20-48			30-9	(1)
	00-23			10-52			10-106			20-49	(1)		30-10	(1)
	00-24			10-53			10-107			20-50	(1)		30-11	(1)
				10-54			10-108			20-51			30-12	(1)
	10-1			10-55			10-109			20-52			30-13	(1)
	10-2			10-56			10-110			20-53			30-14	(1)
	10-3			10-57						20-54			30-15	(1)
	10-4			10-58			20-1	(1)		20-55	(1)		30-16	(1)
	10-5			10-59			20-2	(1)		20-56	(1)		30-17	(1)
	10-6			10-60			20-3			20-57	(1)		30-18	(1)
	10-7			10-61			20-4			20-58	(1)		30-19	(1)
	10-8			10-62			20-5			20-59	(1)		30-20	(1)
	10-9			10-63			20-6			20-59-1	(1)		30-21	(1)
	10-10			10-64			20-7			20-59-2	(1)		30-22	(1)
	10-11			10-65			20-8			20-60	(1)		30-23	(1)
	10-12			10-66			20-9			20-61			30-24	(1)
	10-13			10-67			20-10			20-62			30-25	(1)
	10-14			10-68			20-11			20-63			30-26	(1)
	10-15			10-69			20-12			20-64			30-27	(1)
	10-16			10-70			20-13			20-65	(1)		30-28	(1)
	10-17			10-71			20-14			20-66	(1)		30-29	(1)
	10-18			10-72			20-15			20-67			30-30	(1)
	10-19			10-73			20-16			20-68			30-31	(1)
	10-20			10-74			20-17			20-69			30-32	(1)
	10-21			10-75			20-18			20-70			30-33	(1)
	10-22			10-76			20-19			20-71			30-34	(1)
	10-23			10-77			20-20			20-72			30-35	(1)
	10-24			10-78			20-21			20-73			30-36	(1)
	10-25			10-79			20-22			20-74			30-37	(1)
	10-26			10-80			20-23			20-75			30-38	(1)
	10-27			10-81			20-24			20-76			30-39	(1)
	10-28			10-82			20-25			20-77			30-40	(1)
	10-29			10-83			20-26			20-78			30-41	(1)

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$